



# **KODIAK SNOW BLOWER MAINTENANCE MANUAL & PARTS BOOK**

Warning:

**Read and observe the safety precautions and instructions in this manual and carefully observe the safety labels on the machine. Failure to do so may cause serious injury, death or property loss. Keep this manual accessible at all times.**

## NOTICE:

A SNOW BLOWER is a highly technical and custom piece of equipment meant to operate in adverse weather conditions especially extremely cold temperatures.

Kodiak shall not be liable for any adverse consequences arising from the following circumstances:

- Operation of equipment not in accordance with the information in this manual.
- Lack of maintenance or proper lubrication
- Consequences resulting from unauthorized modification or alteration of the equipment.
- Equipment damage or accident caused by not using OEM parts or using untested or unauthorized parts or tools.
- Kodiak will not be responsible for any failure or damage to the machine due to force majeure such as natural disasters (earthquakes, typhoons, etc.) or political upheaval.

Different regions and local government departments may also have stricter operating regulations for snow blowers. In case of conflict with these safety operating regulations, the more stringent safety operating regulations should be followed.

### Responsibilities of the Kodiak manufacturer

- To providing quality equipment
- Timely after-sales service
- Provide access to training to equipment operators and maintenance personnel.

### Responsibilities of customer or other authorized personnel and management.

- Personnel involved in the operation and maintenance of the snow blower may only operate and maintain the snow blower if they have been systematically

trained and fully understand the instructions including operation and maintenance in this manual.

- Ensure that the operator is trained, fully understands Kodiak's operation and maintenance manual, has any applicable license as is required locally and is in good health.
- Periodically check the safety awareness of all relevant personnel.
- If there is any fault affecting the safety, stop operation immediately.
- Ensure timely maintenance and repair of the equipment.
- Plan the use of the equipment carefully and consciously.

### Responsibilities of all operating personnel

- If there is any phenomenon that may cause abnormal operation of the equipment or if there is potential danger, operation should stop until the situation can be analyzed for safety.
- All personnel working on or around the equipment must obey all warning signals, signs and be vigilant for the safety of themselves and others.
- Pay attention to observe if there is any danger, and report the danger warning to the operator and any pertinent personnel in time.
  - Such as high voltage lines in the operating area, non-personnel, poor ground conditions, etc.

### Table of Contents

#### **Part I Technical description**

1. Technical Overview and Schematics

#### **Part II Inspection and Maintenance**

1. Maintenance
  - 1.1. Maintenance overview
  - 1.2. Oil
  - 1.3. Hydraulic oil
  - 1.4. Fuel
  - 1.5. Coolant for cooling system
  - 1.6. Grease
  - 1.7. Storage of oil and fuel
  - 1.8. Filter element

- 1.9. Electrical system maintenance
2. Lubrication
  - 2.1. Manual lubrication
    - 2.1.1. Blower head lubrication
    - 2.1.2. Chassis lubrication
  - 2.2. Selection standard of lubricating grease
3. Wear Items
4. Maintenance capacity table
5. Filter element
6. Torque specifications
7. Safety critical parts
  - 7.1. Shear pin
8. Maintenance procedure
  - 8.1. Daily maintenance
  - 8.2. Shear pin replacement
  - 8.3. Wiper maintenance
  - 8.4. One month maintenance
    - 8.4.1. Clean the primary filter element
    - 8.4.2. Add coolant
  - 8.5. Six month maintenance
  - 8.6. One year maintenance
    - 8.6.1. Replace the air filter element
    - 8.6.2. Oil change and oil filter
    - 8.6.3. Replace the filter element of oil-water separator
    - 8.6.4. Replace the fuel filter
    - 8.6.5. Change the lubricating oil of traveling transfer case
    - 8.6.6. Change axle oil
    - 8.6.7. Change hydraulic oil and filter element of hydraulic system
    - 8.6.8. Changing gearbox oil
    - 8.6.9. Replace air dryer filter element
    - 8.6.10. Discharge of water and sediment from the fuel tank
  - 8.7. Two year maintenance
    - 8.7.1. Changing the coolant
    - 8.7.2. Changing transmission oil
9. Other
  - 9.1. Tire change
  - 9.2. Replace the belt
  - 9.3. Fan replacement
  - 9.4. Battery replacement

### **Part III Safety, Troubleshooting, Assembly & Disassembly**

1. Safety Instruction
  - 1.1. Maintenance Personnel
  - 1.2. Risks in maintenance
  - 1.3. Precautions before maintenance
  - 1.4. Precautions in maintenance work
2. **Troubleshooting, Assembly & Disassembly**


## 2.1. Troubleshooting

### Part IV Parts List and List of Tools

1. Parts lists
2. List of Tools
3. Warranty Procedure

## Part I Section 1. Technical description and Schematics.

### Major Components



1. Blower Head. See Part II for maintenance & IV for specification details.
2. Cab. See Part IV for specification details.
3. Hydraulic Tank. See Part II for maintenance & IV for specification details.
4. Transmission. See Part II for maintenance and Part III Annex III for full service manual

5. Air Filter. See Part II for maintenance
6. Exhaust Muffler. See Part IV for specification details.
7. Engine. See Part II for maintenance and Part III Annex III for full service manual, and Part IV for adjacent parts.
8. Radiator. See Part II for maintenance & IV for specification details.
9. Pump. See Part II for maintenance and Part III Annex III for full service manual, and Part IV for adjacent parts.
10. Spare Tire. See Part II for maintenance & IV for specification details.
11. Fuel Tank. See Part II for maintenance & IV for specification details.
12. Rear Axle. See Part II for maintenance and Part III Annex III for full service manual, and Part IV for adjacent parts.
13. Heater. See Part II IV for specification details.
14. Motor. See Part II for maintenance and Part III Annex III for full service manual, and Part IV for adjacent parts.
15. Transfer Case. See Part II for maintenance and Part III Annex III for full service manual, and Part IV for adjacent parts.
16. Front Axle. See Part II for maintenance and Part III Annex III for full service manual, and Part IV for adjacent parts.

# Part I

# CR580S

Length (With spare tire & cutter bar): 8761mm

Height: 3523mm

Length (With spare tire): 8311mm


Gross Weight: 14350Kg


Width (Chassis): 2627mm

Front Axle: 7900Kg


Width (With Blower): 2784mm

Rear Axle: 6450Kg











3523




2784




# Hydraulic Schematics, models & diagrams







Pressure Gage




Pressure Sensor




Thermostat




Filter




Cooler




Tank




Grease Block




Check Valve



Manual Emergency Valve




Flow Control Valve




Refill/Relief Valve




Throttle Valve




Throttle Valve




Pilot Operated Check Valve




Reducing Valve




Lock Valve




Relief Valve




"Y" Directional Control Valve




"O" Directional Control Valve




"N" Directional Control Valve




Gear Pump




Constant Pressure Pump




Drive Pump




Gear motor



Cylinder



Steering Unit




Drive Motor

| Num | Part Num.          | Description     | Quantity |
|-----|--------------------|-----------------|----------|
| 1   | CBHB-F550-AF15     | Fan Drive Pump  | 1        |
| 2   | CMF-E550S-AFPS     | Fan Drive Motor | 1        |
| 3   | KP30.31S0          | Steering Pump   | 1        |
| 4   | PV_JR_L_S45B_PC_21 | Work Pump       | 1        |
| 5   | HPV02-105L-E1D2    | Drive Pump      | 1        |
| 6   | HMV105-E6          | Linde motor     | 1        |

### Working pressures


- 1. 0-200 bar
- 3. 0-120 bar
- 4. 0-140 bar
- 5. 0-420 bar



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|                      |          |   |   |                       |
|----------------------|----------|---|---|-----------------------|
| DRAWING NOT TO SCALE |          | UNLESS OTHERWISE SPECIFIED:<br>DIMENSIONS ARE IN INCHES<br>Dual dimensions are in mm<br>Reference dimensions are in ( )<br><br>TOLERANCES:<br>Fractional: 1/8"<br>Angular: MACH ± 0.5° BEND<br>Machined/Drilled Holes:<br><br>All Others<br>xx ±0.10<br>x.xx ±0.06<br>x.xxx ±0.03 | Part Description<br><b>Pump-Motor</b><br><br>Part Number<br><b>550S-0500000-3</b> | Revision<br><b>-0</b> |
| MATERIAL             | ASSEMBLY | DRAWN BY: JND    DATE: 01/04/2020<br>SCALE: 3,2    WEIGHT:    SHEET 1 OF 1  |   |                       |



1

KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |
|----------|
| MATERIAL |
| ASSEMBLY |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:  
 All Others  
 .xx ±0.10  
 x.xx ±0.06  
 0.03

Part Description  
**Hydraulic Schematic Diagram**

Part Number  
**CR550S-0800100**

Revision  
 -0

DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1

| Num | Part Num.                                 | Description                    | Quantity |
|-----|---|--------------------------------|----------|
| 1   | CR550S-320L                               | Hydraulic Tank                 | 1        |
| 2   | PV-JR-L-S45B-PC-21                        | Work pump                      | 1        |
| 3   | PBF0160F010NB16N                          | Hydraulic Pressure Filter      | 1        |
| 4   | SC2-M1H1E-4L20009                         | Hydraulic Valve Bank           | 1        |
| 5   | EPC102CN-P21F40-G06-24DD/C023320801301404 | Flow control Valve             | 1        |
| 6   | PVG32-1                                   | Danfoss Manual Emergency Valve | 1        |
| 7   | EC102CN-P25F76-G06-24DD                   | Lock Valve                     | 2        |
| 8   | K06672                                    | Rear Steering Cylinder         | 2        |
| 9   | EC102CN-P25F76-G06-24DD                   | Lock Valve                     | 2        |
| 10  | K04398                                    | Lift Cylinder                  | 2        |
| 11  | Transfer case                             | Shift Cylinder                 | 1        |
| 12  | GCRV102-S36-M1G06                         | Relief Valve                   | 1        |
| 13  | K01120/K90013                             | Volute Cylinder                | 1        |
| 14  | AH0900316S                                | Grease Block                   | 1        |
| 15  | KP30.31S0                                 | Steering Pump                  | 1        |
| 16  | OSPC500                                   | Steering Gear                  | 1        |
| 17  | K06672                                    | Front Steering Cylinder        | 2        |
| 18  | CBHB-F550-AF15                            | Fan Drive Pump                 | 1        |
| 19  | RV-DN12-G1/2                              | Check Valve                    | 1        |
| 20  | CMF-E550-AFPS                             | Fan Drive Motor                | 1        |
| 21  | B-0700065I22Y                             | Hydraulic Radiator             | 1        |
| 22  | TV-12                                     | Thermostat                     | 1        |
| 23  | HPV02-105L-E1D2                           | Drive Pump/Charge pump         | 1        |
| 24  | 638008A4G13LP0L6MP/#-XPQT7                | Pressure Gage                  | 1        |
| 25  | S3550                                     | Pressure Sensor                | 1        |
| 26  | HMV105-E6                                 | Linde Motor                    | 1        |

UNLESS OTHERWISE SPECIFIED:  
DIMENSIONS ARE IN INCHES  
Dual dimensions are in mm  
Reference dimensions are in ( )

TOLERANCES:  
Fractional: 1/8"  
Angular: MACH ±0.5° BEND  
Machined/Drilled Holes:

All Others  
x.x ±0.10  
x.xx ±0.06  
0.03

|  |                 |                                 |
|--|-----------------|---------------------------------|
| Part Description<br><b>Hydraulic Schematic Diagram</b> |                 | Revision<br>-0                  |
| Part Number<br><b>CR550S-0800100</b>                   |                 |                                 |
| DRAWN BY JND   | DATE 01/04/2020 | SCALE: 3:2 WEIGHT: SHEET 1 OF 1 |


KODIAK

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
KODIAK AMERICA IS PROHIBITED.

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

DRAWING NOT TO SCALE

| Num | Part Num.          | Description                | Quantity |
|-----|--------------------|----------------------------|----------|
| 1   | XYF10-08           | Relief Valve               | 1        |
| 2   | DASV10-28-0-N-00DR | Lock Valve                 | 1        |
| 3   | LPPR-10-30         | Relief Valve               | 1        |
| 4   | WDMFA06-AJB        | Directional Control Valves | 1        |
| 5   | MSW-01-X-30        | Throttle Valve             | 1        |
| 6   | LDPR-08-6          | Relief Valve               | 1        |
| 7   | WDMFA06-ADB        | Directional Control Valves | 1        |
| 8   | WDMFA06-ADB        | Directional Control Valves | 1        |
| 9   | MPW-01-4-40        | Two-way Yydraulic Lock     | 1        |
| 10  | MPW-01-X-30        | Throttle Valve             | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE


|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractions: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:  
 All Others:  
 .xx ±0.10  
 .xxx ±0.06  
 .003

|   |                    |              |              |
|---|--------------------|--------------|--------------|
| Part Description<br><b>Valve Bank</b>       |                    |              |              |
| Part Number<br><b>SC2-M1H1EH-4L20009-V1</b> |                    | -0           |              |
| DRAWN BY<br>JND                             | DATE<br>01/04/2020 | SCALE<br>3:2 | WEIGHT       |
|   |                    |              | SHEET 1 OF 1 |

# Water Schematics, models & diagrams

| Num | Part Num.         | Description               | Quantity |
|-----|-------------------|---------------------------|----------|
| 1   | QSZ13-C550        | Engine                    | 1        |
| 2   | C2874497          | Water                     | 1        |
| 3   | ∅16               | Tube                      | 1        |
| 4   | C4952629          | Thermostat                | 1        |
| 5   | ∅63.5             | Tube                      | 1        |
| 6   | Y000084           | Radiator                  | 1        |
| 7   | ∅63.5             | Tube                      | 1        |
| 8   | 4974917           | Pump                      | 1        |
| 9   | C2874497          | Water-Return              | 1        |
| 10  | ∅16               | Tube                      | 1        |
| 11  | YJH-Q15A.24V      | Heater                    | 1        |
| 12  | ∅16               | Tube                      | 1        |
| 13  | ∅16               | Tube                      | 1        |
| 14  | TY46G15AB-ZGZQ-09 | Cab heater/heat exchanger | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

MATERIAL \_\_\_\_\_  
 ASSEMBLY \_\_\_\_\_

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:

All Others  
 xx ±0.10  
 xxx ±0.06  
 0.03

Part Description

Engine Pre-heating

Part Number

CR550S-HEATER+RADIATOR

Revision

-0


DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1

| Num | Part Num.           | Description   | Quantity |
|-----|---------------------|---------------|----------|
| 1   | 12JSDX240TA         | Transmission  | 1        |
| 2   | FJ601011            | Washer        | 2        |
| 3   | 10JSX220A-1708091-1 | Joint         | 2        |
| 4   | 2Q9-16Z             | Joint         | 2        |
| 5   | 10JSX220A-1708092-1 | Hose assembly | 2        |
| 6   | Ø18                 | Hoop          | 2        |
| 7   | 10JSX220A-1708080-1 | Radiator      | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE


|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractional ± 1/8"  
 Angular: MACH ± 0.5° BEND ± 2°  
 Machined/Drilled Holes: ± 0.01  
 All Others  
 x.x ± 0.10  
 x.xx ± 0.06  
 x.xxx ± 0.03

|  |                    |                       |        |
|--|--------------------|-----------------------|--------|
| Part Description<br><b>Transmission Cooling Assembly</b> |                    | Revision<br><b>-0</b> |        |
| Part Number<br><b>12JSDX240TA-01</b>                     |                    |                       |        |
| DRAWN BY<br>JND  | DATE<br>01/04/2020 | SCALE<br>3.2          | WEIGHT |
|  |                    | SHEET 1 OF 1          |        |

# Electrical Schematics, models & diagrams

| Wire colors abbreviation |    |
|--------------------------|----|
| Red                      | RD |
| Black                    | BK |
| White                    | WT |
| Pink                     | PK |
| Purple                   | PL |
| Blue                     | BU |
| Green                    | GN |
| Yellow                   | YE |
| Orange                   | OG |
| Gray                     | GY |
| Brown                    | BN |



Potentiometer




Sensor




Power supply



Shielded wire



Fuse




Electrical connector



Resistor




Grounding





Magnetic induction sensor



Pressure Switch



Hydraulic solenoid valve



|                       |        |     |
|-----------------------|--------|-----|
| Steer Valve Lock 1    | WH-017 | S18 |
| Rear Steer Flow Valve | WH-016 | S17 |
| Rear L (L+Switch)     | WH-015 | S16 |
| Rear R (R+Switch)     | WH-014 | S15 |
| Blower UP             | WH-013 | S14 |
| Blower Down           | WH-012 | S13 |
| Volute L              | WH-011 | S12 |
| Volute R              | WH-010 | S11 |









|               |        |     |
|---------------|--------|-----|
| SPARE         | S02    |     |
| SPARE         | S03    |     |
| SPARE         | S04    |     |
| SPARE         | S05    |     |
| SPARE         | S06    |     |
| Travel Lock 1 | WH-006 | S07 |
| Travel Lock 2 | WH-007 | S08 |
| Plow Float    | WH-008 | S09 |

|                     |        |     |
|---------------------|--------|-----|
| SPARE               | E18    |     |
| SPARE               | E17    |     |
| Pump FWD Valve      | WH-053 | E16 |
| PumpREV Valve       | WH-052 | E15 |
| Travel Motor Valve  | WH-051 | E14 |
| Gearbox Low Valve   | WH-050 | E13 |
| Steer Valve Lock 2  | WH-049 | E12 |
| Gearbox Hight Valve | WH-048 | E11 |

|                 |        |     |
|-----------------|--------|-----|
| Diff Lock Valve | WH-046 | E02 |
| SPARE           | E03    |     |
| SPARE           | E04    |     |
| SPARE           | E05    |     |
| SPARE           | E06    |     |
| SPARE           | E07    |     |
| SPARE           | E08    |     |
| SPARE           | E09    |     |

|               |        |     |
|---------------|--------|-----|
| SPARE         | E25    |     |
| SPARE         | E26    |     |
| SPARE         | E27    |     |
| Back UP Alarm | YE-061 | E28 |
| SPARE         | E29    |     |
| SPARE         | E30    |     |
| SPARE         | E31    |     |
| Engine Start  | YE-071 | E50 |

|              |        |     |
|--------------|--------|-----|
| SPARE        | E42    |     |
| SPARE        | E43    |     |
| SPARE        | E44    |     |
| SPARE        | E45    |     |
| System Alarm | WH-069 | E46 |
| SPARE        | E47    |     |
| SPARE        | E48    |     |
| SPARE        | E49    |     |



| PB 9-968974-2 |                            |
|---------------|----------------------------|
| 1             | Bark lights WH-45          |
| 2             | Clearer light WH-48        |
| 3             | Engine house lights RD-116 |
| 4             |                            |
| 5             | Switch lamp RD-161         |
| 6             | Heating RD-139             |
| 7             | Strobe lights RD-115       |
| 8             |                            |
| 9             | Clearer light RD-111       |
| 10            | Ground lead BK-140         |
| 11            |                            |
| 12            | Steering coln PWR RD-131   |
| 13            |                            |
| 14            |                            |
| 15            |                            |
| 16            | 24V charge point WH-19     |
| 17            | Engine ECM PWR RD-080      |
| 18            |                            |

| PC 9-968974-1 |                          |
|---------------|--------------------------|
| 1             |                          |
| 2             |                          |
| 3             | Cab Fans WH-9411         |
| 4             |                          |
| 5             |                          |
| 6             |                          |
| 7             |                          |
| 8             |                          |
| 9             | Diagnostic PWR RD-089    |
| 10            |                          |
| 11            | Clutch switch PWR RD-099 |
| 12            | Cab step light WH-6      |
| 13            |                          |
| 14            |                          |
| 15            |                          |
| 16            | Cab lights WH-7612       |
| 17            | Lo Beam WH-46            |
| 18            |                          |

| PD 9-968975-1 |                            |
|---------------|----------------------------|
| 1             | Wiper PWR WH-10            |
| 2             | Clutch control BU/ND       |
| 3             | Windows motor WH-3         |
| 4             |                            |
| 5             |                            |
| 6             |                            |
| 7             | Hi beam WH-47              |
| 8             |                            |
| 9             | Mirror PWR WH-2            |
| 10            |                            |
| 11            |                            |
| 12            | Radio PWR WH-1             |
| 13            |                            |
| 14            |                            |
| 15            |                            |
| 16            |                            |
| 17            | L glass heating WH-17      |
| 18            | Parking brake valve RD-100 |
| 19            |                            |
| 20            |                            |
| 21            | Spot lights PWR WH-13      |

| PE 9-968975-1 |                       |
|---------------|-----------------------|
| 1             |                       |
| 2             |                       |
| 3             | R wiper park WH-47    |
| 4             |                       |
| 5             |                       |
| 6             | R wiper park n1 WH-41 |
| 7             |                       |
| 8             |                       |
| 9             | R wiper park n2 WH-41 |
| 10            |                       |
| 11            |                       |
| 12            |                       |
| 13            |                       |
| 14            |                       |
| 15            |                       |
| 16            |                       |
| 17            |                       |
| 18            |                       |
| 19            |                       |
| 20            |                       |
| 21            |                       |

| G D706-12S |                                     |
|------------|-------------------------------------|
| 1          | GND BK-176 U                        |
| 2          | Switch PWR RD-166 PG-2              |
| 3          | Engine Throttle Signal YE-044 IS-56 |
| 4          | Throttle PWR RD-040 IS-51           |
| 5          | Diff Lock Switch WH-059 IS-24       |
| 6          |                                     |
| 7          | Transfer case High WH-062 IS-23     |
| 8          | Travel Lock Switch WH-068 IS-41     |
| 9          | Flow Float Switch WH-058 IS-23      |
| 10         | Rear Steer Switch WH-072 IS-23      |
| 11         | Switch lamp RD-161 PS-6             |
| 12         |                                     |

| C Joystick D706-4S |                           |
|--------------------|---------------------------|
| 1                  | GND BK-179 U              |
| 2                  | Joystick PWR RD-173 PH-17 |
| 3                  | CAN 3 H J13/GN-037 IS-45  |
| 4                  | CAN 3 L J13/YT-024 IS-27  |
| 5                  | CAN SHIELD U              |
| 6                  |                           |

| K Stroker 174045-2 |                                 |
|--------------------|---------------------------------|
| 1                  | Stroker PWR RD-172 PH-15        |
| 2                  | Stroker REV Signal YE-029 IS-35 |
| 3                  |                                 |
| 4                  |                                 |
| 5                  | Stroker PWR RD-172 PH-15        |
| 6                  | Stroker FWD Signal WH-043 IS-54 |
| 7                  | Stroker PWR RD-172 PH-15        |
| 8                  | Stroker REV Switch WH-042 IS-53 |

| M IFM Display D706-4S |                              |
|-----------------------|------------------------------|
| 1                     | GND BK-180 U                 |
| 2                     | IFM display PWR RD-170 PH-12 |
| 3                     | CAN 2 H J13/GN-036 IS-46     |
| 4                     | CAN 2 L J13/YT-025 IS-28     |

| N Fault light AMP-8S |                           |
|----------------------|---------------------------|
| 1                    | GND BK-181 U              |
| 2                    | Lamp PWR RD-167 PG-6      |
| 3                    | Check Engine YE-062 IS-17 |
| 4                    | Stop Engine YE-093 IS-18  |
| 5                    | Wait Engine YE-094 IS-18  |
| 6                    | System Alarm WH-069 IS-46 |

| V Charge Point 282080-1 |                           |
|-------------------------|---------------------------|
| 1                       | GND BK-184 U              |
| 2                       | Charge Point RD-169 PG-20 |

| XE IFM Controller-E 828907-1 |  |
|------------------------------|--|
| GND                          | E20/E37 GND BK-055 U                   |
| PWR                          | E10/E32 PWR RD-047 PH-9                |
| PWR                          | E01/E19/E51 PWR RD-045 PH-2            |
| E-02                         | Diff Lock Valve WH-046 A-1             |
| E-11                         | Transfer case High Valve WH-048 B-31   |
| E-12                         | Transfer case Low Valve WH-049 A-2     |
| E-13                         | Transfer case Valve WH-050 B-33        |
| E-14                         | Travel Motor Valve WH-051 A-3          |
| E-15                         | Pump/FWD Valve WH-052 A-4              |
| E-16                         | Pump/FWD Valve WH-053 A-5              |
| E-22                         | Transfer case Fast Feedback WH-057 A-6 |
| E-23                         | Flow Float Switch WH-058 C-9           |
| E-24                         | Diff Lock Switch WH-059 C-5            |
| E-28                         | Back Up Alarm YE-061 PG-16             |
| E-33                         | Transfer case High Switch WH-062 C-7   |
| E-35                         | Hyd Oil level switch WH-063 B-35       |
| E-36                         | Brake signal YE-064 D-2                |
| E-39                         | Rear Diff Lock Feedback WH-066 A-8     |
| E-40                         | Transfer case Slow Feedback WH-067 A-9 |
| E-41                         | Travel Lock Switch WH-068 C-8          |
| E-46                         | System Alarm WH-069 M-6                |
| E-50                         | Engine Start YE-071 PJ-21              |
| E-52                         | Rear Steer Switch WH-072 C-10          |
| E-54                         | Emergency Stop-NC WH-074 PJ-19         |
| E-55                         | Parking brake signal YE-075 L-2        |

| XS IFM Controller-S 828907-1 |                                      |
|------------------------------|--------------------------------------|
| 1                            | S20/S37/S42 GND BK-018 1.0 U         |
| 2                            | S01/S19 PWR RD-001 1.0 PH-5          |
| 3                            | S50/S32/S10 PWR RD-009 1.0 PH-5      |
| S-07                         | Travel Lock 1 WH-006 B-7             |
| S-08                         | Travel Lock 2 WH-007 B-8             |
| S-09                         | Flow Float WH-008 B-9                |
| S-11                         | Volume R WH-010 B-11                 |
| S-12                         | Volume L WH-011 B-12                 |
| S-13                         | Blower Down WH-012 B-13              |
| S-14                         | Blower Up WH-013 B-14                |
| S-15                         | Rear R (R+Trigger) WH-014 B-15       |
| S-16                         | Rear L (L+Trigger) WH-015 B-16       |
| S-17                         | Rear Steer Flow Valve WH-016 B-17    |
| S-18                         | Steer Valve Lock 1 WH-017 A-12       |
| S-22                         | Accelerator Pedal WH-019 IS-8        |
| S-23                         | Make up Pressure Switch WH-020 B-23  |
| S-24                         | FWD Pressure signal WH-021 A-13      |
| S-25                         | Download port-3 YF-022 S-3           |
| S-26                         | CAN 3 L YF-023 1.0 R-4               |
| S-27                         | CAN 3 L YF-024 1.0 C-4               |
| S-28                         | CAN 2 L YF-025 1.0 M-4               |
| S-29                         | CAN 1 L YF-026 1.0 T-B               |
| S-33                         | Front Diff Lock Feedback WH-027 A-14 |
| S-34                         | Hyd Oil Temperature WH-028 B-34      |
| S-35                         | Stroker REV Signal YE-029 E-2        |
| S-36                         | Engine Start Switch YE-030 JS-2      |
| S-38                         | Transfer case speed WH-031 A-15      |
| S-39                         | Air Pressure WH-032 B-39             |
| S-40                         | Working Pump Sensor YE-033 B-40      |
| S-41                         | Deceleration Pedal YE-034 IS-B       |
| S-43                         | Download port-3 GN-035 1.0 S-2       |
| S-44                         | CAN 4 H GN-036 1.0 R-3               |
| S-45                         | CAN 3 H GN-037 1.0 C-3               |
| S-46                         | CAN 2 H GN-038 1.0 M-3               |
| S-47                         | CAN 1 H GN-039 1.0 T-A               |
| S-51                         | Throttle PWR RD-040 G-4/IS-C/XS-C    |
| S-52                         | Fuel Level WH-041 A-16               |
| S-53                         | Stroker REV Switch WH-042 E-6        |
| S-54                         | Stroker FWD Signal WH-043 E-6        |
| S-55                         | Engine Throttle Signal YE-044 G-3    |

| PF 9-968975-2 |                          |
|---------------|--------------------------|
| 1             |                          |
| 2             |                          |
| 3             | Front wiper J RD-106     |
| 4             | Washer RD-107            |
| 5             |                          |
| 6             | Washer pump WH-7+9 1.5   |
| 7             |                          |
| 8             |                          |
| 9             | R glass heating WH-28    |
| 10            |                          |
| 11            |                          |
| 12            |                          |
| 13            | Flash PWR RD-121         |
| 14            |                          |
| 15            | L wiper motor n2 WH-LH   |
| 16            | Glass heating YE-127     |
| 17            | Sid wiper n1 RD-128      |
| 18            | L wiper motor n1 WH-L    |
| 19            | Sid wiper n2 RD-129      |
| 20            | L wiper motor park WH-LF |
| 21            |                          |

| PG 9-968975-1 |                           |
|---------------|---------------------------|
| 1             | Brake lights RD-112       |
| 2             | Switch PWR RD-166         |
| 3             | Sensor PWR RD-077         |
| 4             | Glass heating YE-127      |
| 5             | Brake signal YE-064       |
| 6             | Lamp PWR RD-167           |
| 7             |                           |
| 8             | Clutch control BU/ND      |
| 9             | Steering coln PWR RD-185  |
| 10            | Ground lead BK-185        |
| 11            |                           |
| 12            | Filter heating PWR RD-082 |
| 13            | Lo beam signal YE-119     |
| 14            |                           |
| 15            | Air dry PWR RD-083        |
| 16            | IFM Back up alarm YE-061  |
| 17            | Hi beam signal YE-130     |
| 18            | Pressure switch 3 RD-078  |
| 19            | Back up alarm RD-114      |
| 20            | Charge Point RD-169       |
| 21            | Display PWR RD-096        |

| PH 9-968974-1 |                           |
|---------------|---------------------------|
| 1             | Back up lights RD-113     |
| 2             | Controller 3 PWR RD-045   |
| 3             | Pressure switch 2 RD-087  |
| 4             |                           |
| 5             | Controller 4 PWR RD-009   |
| 6             | Controller 1 PWR RD-001   |
| 7             | Back up light SW YE-126   |
| 8             | Pressure switch 1 RD-086  |
| 9             | Controller 2 PWR RD-047   |
| 10            |                           |
| 11            |                           |
| 12            | IFM display PWR RD-170    |
| 13            | Sensor PWR RD-171         |
| 14            | Stroker PWR RD-172        |
| 15            |                           |
| 16            |                           |
| 17            | Working handle PWR RD-173 |
| 18            | Brake switch PWR RD-133   |

| PJ 7-968975-1 |                                   |
|---------------|-----------------------------------|
| 1             | IGN 15+ PWR RD-132                |
| 2             | Emergency stop PWR RD-117         |
| 3             | Generator PWR RD-188              |
| 4             | IGN 15+ PWR RD-132                |
| 5             | Clutch control BU/ND 0.75         |
| 6             | A/C PWR RD-098                    |
| 7             | Strobe lights SW YE-123           |
| 8             | Clearer light SW RD-124           |
| 9             | Baton neutral signal YE-086 PJ-18 |
| 10            | Ground lead BK-174                |
| 11            |                                   |
| 12            | Clutch brake WH/ND 0.85           |
| 13            | Work lights SW YE-125             |
| 14            | Emergency stop NO WH-118          |
| 15            | Engine start PWR YE-079           |
| 16            |                                   |
| 17            | Baton neutral signal YE-086 PJ-9  |
| 18            | Engine IGN 15+ RD-081             |
| 19            | Strobe lights WH-50 2.0           |
| 20            |                                   |
| 21            | Engine start signal YE-071        |

| F Turn signal lamp 282087-1 |                     |
|-----------------------------|---------------------|
| 1                           | Turn R YE-109 JS-12 |
| 2                           | Turn L YE-110 JS-4  |
| 3                           |                     |

| E Horn 1-967325-1 |                      |
|-------------------|----------------------|
| 1                 | GND BK-134 U         |
| 2                 | Horn PWR YE-122 JS-5 |


| D Brake switch |                               |
|----------------|-------------------------------|
| 1              | Brake switch PWR RD-133 PH-18 |
| 2              | Brake signal YE-064 IS-36PG-6 |

| J1 Steering coln D704-6P |  |
|--------------------------|--|
| 1                        | Turn R YE-109 JS-12                    |
| 2                        | Hi beam signal YE-120 JS-2             |
| 3                        | Parking brake signal YE-075 L-2        |
| 4                        | Transfer case Fast Feedback WH-067 A-6 |
| 5                        | Transfer case Slow Feedback WH-067 A-9 |
| 6                        | Turn L YE-110 JS-4                     |

| J2 Steering coln D704-12P |                                  |
|---------------------------|----------------------------------|
| 1                         | Lo beam signal YE-119 PG-13      |
| 2                         | Hi beam signal YE-120 PG-13AJ1-2 |
| 3                         | Flash PWR RD-121 PF-13AJ2-2      |
| 4                         | Steering coln PWR RD-185 PG-9    |
| 5                         | Horn PWR YE-122 E-2              |
| 6                         | Washer RD-107 XT-7AP-4           |
| 7                         | Steering coln PWR RD-185 PG-9    |
| 8                         | Front wiper J RD-106 XT-3AP-3    |
| 9                         | Front wiper n2 WH-LH XT-4        |
| 10                        | Front wiper n1 WH-LH XT-2        |
| 11                        | Front wiper return WH-104 XT-6   |
| 12                        | Turn R YE-109 XT-2AP-1AJ1-1      |

| J3 Steering coln D704-6P |                                  |
|--------------------------|----------------------------------|
| 1                        | Steering coln PWR RD-131 PH-12   |
| 2                        | Engine Start Switch YE-030 JS-36 |
| 3                        | IGN 15+ PWR RD-132 PJ-1APJ-4     |
| 4                        | Turn L YE-110 P-2AP-3AJ1-6       |
| 5                        | Steering coln PWR RD-185 PG-9    |
| 6                        | High beam signal RD-187 JS-8     |

| A Engine wire harness |   |
|-----------------------|---|
| A                     | Engine start PWR YE-079 PJ-15                 |
| B                     | Engine ECM PWR RD-080 PH-17                   |
| C                     | Engine IGN 15+ RD-081 PJ-19                   |
| D                     | Filter heating PWR RD-082 PG-12               |
| E                     | Air dry PWR RD-083 PG-15                      |
| F                     | Clutch brake WH/ND PJ-12                      |
| G                     | Baton neutral signal YE-086 PJ-18             |
| H                     | Clutch switch WH-088 IS-2                     |
| I                     | Pressure switch 2 PWR RD-087 PH-3             |
| J                     | Pressure switch 1 RD-088 PH-4                 |
| K                     | Diagnostic PWR RD-089 PH-9                    |
| L                     | Generator PWR RD-188 PJ-3                     |
| M                     | Diff Lock Valve WH-046 IS-2                   |
| N                     | Steer Valve Lock 2 WH-049 IS-11               |
| O                     | Drive Motor Valve WH-051 IS-14                |
| P                     | Pump/FWD Valve WH-052 IS-15                   |
| Q                     | Pump FWD Valve WH-053 IS-16                   |
| R                     | Transfer case Fast Feedback WH-057 IS-23AJ1-4 |
| S                     | Rear Diff Lock Feedback WH-066 IS-39          |
| T                     | Transfer case Slow Feedback WH-067 IS-40AJ1-5 |
| U                     |   |
| V                     |   |
| W                     |   |
| X                     |   |
| Y                     |   |
| Z                     |   |
| AA                    |   |
| AB                    |   |
| AC                    |   |
| AD                    |   |
| AE                    |   |
| AF                    |   |
| AG                    |   |
| AH                    |   |
| AI                    |   |
| AJ                    |   |
| AK                    |   |
| AL                    |   |
| AM                    |   |
| AN                    |   |
| AO                    |   |
| AP                    |   |
| AQ                    |   |
| AR                    |   |
| AS                    |   |
| AT                    |   |
| AU                    |   |
| AV                    |   |
| AW                    |   |
| AX                    |   |
| AY                    |   |
| AZ                    |   |
| BA                    |   |
| BB                    |   |
| BC                    |   |
| BD                    |   |
| BE                    |   |
| BF                    |   |
| BG                    |   |
| BH                    |   |
| BI                    |   |
| BJ                    |   |
| BK                    |   |
| BL                    |   |
| BM                    |   |
| BN                    |   |
| BO                    |   |
| BP                    |   |
| BQ                    |   |
| BR                    |   |
| BS                    |   |
| BT                    |   |
| BU                    |   |
| BV                    |   |
| BW                    |   |
| BX                    |   |
| BY                    |   |
| BZ                    |   |
| CA                    |   |
| CB                    |   |
| CC                    |   |
| CD                    |   |
| CE                    |   |
| CF                    |   |
| CG                    |   |
| CH                    |   |
| CI                    |   |
| CJ                    |   |
| CK                    |   |
| CL                    |   |
| CM                    |   |
| CN                    |   |
| CO                    |   |
| CP                    |   |
| CQ                    |   |
| CR                    |   |
| CS                    |   |
| CT                    |   |
| CU                    |   |
| CV                    |   |
| CW                    |   |
| CX                    |   |
| CY                    |   |
| CZ                    |   |
| DA                    |   |
| DB                    |   |
| DC                    |   |
| DD                    |   |
| DE                    |   |
| DF                    |   |
| DG                    |   |
| DH                    |   |
| DI                    |   |
| DJ                    |   |
| DK                    |   |
| DL                    |   |
| DM                    |   |
| DN                    |   |
| DO                    |   |
| DP                    |   |
| DQ                    |   |
| DR                    |   |
| DS                    |   |
| DT                    |   |
| DU                    |   |
| DV                    |   |
| DW                    |   |
| DX                    |   |
| DY                    |   |
| DZ                    |   |
| EA                    |   |
| EB                    |   |
| EC                    |   |
| ED                    |   |
| EE                    |   |
| EF                    |   |
| EG                    |   |
| EH                    |   |
| EI                    |   |
| EJ                    |   |
| EK                    |   |
| EL                    |   |
| EM                    |   |
| EN                    |   |
| EO                    |   |
| EP                    |   |
| EQ                    |   |
| ER                    |   |
| ES                    |   |
| ET                    |   |
| EU                    |   |
| EV                    |   |
| EW                    |   |
| EX                    |   |
| EY                    |   |
| EZ                    |   |
| FA                    |   |
| FB                    |   |
| FC                    |   |
| FD                    |   |
| FE                    |   |
| FF                    |   |
| FG                    |   |
| FH                    |   |
| FI                    |   |
| FJ                    |   |
| FK                    |   |
| FL                    |   |
| FM                    |   |
| FN                    |   |
| FO                    |   |
| FP                    |   |
| FQ                    |   |
| FR                    |   |
| FS                    |   |
| FT                    |   |
| FU                    |   |
| FV                    |   |
| FW                    |   |
| FX                    |   |
| FY                    |   |
| FZ                    |   |
| GA                    |   |
| GB                    |   |
| GC                    |   |
| GD                    |   |
| GE                    |   |
| GF                    |   |
| GG                    |   |
| GH                    |   |
| GI                    |   |
| GJ                    |   |
| GK                    |   |
| GL                    |   |
| GM                    |   |
| GN                    |   |
| GO                    |   |
| GP                    |   |
| GQ                    |   |
| GR                    |   |
| GS                    |   |
| GT                    |   |
| GU                    |   |



**KODIAK**

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE


|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0,01

All Others  
 x.x ±0,10  
 x.xx ±0,06  
 x.xxx ±0,03

|  |  |                                 |  |
|--|--|---------------------------------|--|
| Part Description<br><b>Console harness</b> |  | Revision<br><b>-0</b>           |  |
| Part Number<br><b>550S-0901002</b>         |  | SCALE: 3:2 WEIGHT: SHEET 1 OF 1 |  |
| DRAWN BY JND DATE 01/04/2020               |  |                                 |  |



| PB 9-968974-2 |                    |           |
|---------------|--------------------|-----------|
| 1             | Work lights        | WT-45 2.0 |
| 2             | Clearer light      | WT-48 1.5 |
| 3             | Engin house lights | RD-116    |
| 4             |                    |           |
| 5             | Switch lamp        | RD-161    |
| 6             | Heating            | RD-139    |
| 7             | Strobe lights      | RD-115    |
| 8             |                    |           |
| 9             | Clearer light      | RD-111    |
| 10            | Ground lead        | BK-140    |
| 11            |                    |           |
| 12            | Steering colm PWR  | RD-131    |
| 13            |                    |           |
| 14            |                    |           |
| 15            |                    |           |
| 16            | Cigarette lighter  | WT-19 2.5 |
| 17            | Engine ECM PWR     | RD-080    |
| 18            |                    |           |

| PC 8-968974-1 |                   |              |
|---------------|-------------------|--------------|
| 1             |                   |              |
| 2             |                   |              |
| 3             | Fans PWR          | WT-9+11 1.25 |
| 4             |                   |              |
| 5             |                   |              |
| 6             |                   |              |
| 7             |                   |              |
| 8             |                   |              |
| 9             | Diagnostic PWR    | RD-089       |
| 10            |                   |              |
| 11            | Clutch switch PWR | RD-099       |
| 12            | Cab step light    | WH-6 1.5     |
| 13            |                   |              |
| 14            |                   |              |
| 15            | Cab lights        | WH-7+12 2.0  |
| 16            | Lo Beam           | WH-46 2.0    |
| 17            |                   |              |
| 18            |                   |              |

| PD 5-968975-1 |                 |            |
|---------------|-----------------|------------|
| 1             | Wiper PWR       | WH-10 2.5  |
| 2             | Clutch control  | BU/RD 0.75 |
| 3             | Windows motor   | WH-3 2.0   |
| 4             |                 |            |
| 5             |                 |            |
| 6             | Hi beam         | WH-47 2.0  |
| 7             |                 |            |
| 8             |                 |            |
| 9             | Mirrorr PWR     | WH-2 2.0   |
| 10            |                 |            |
| 11            |                 |            |
| 12            | Radio PWR       | WH-1 1.25  |
| 13            |                 |            |
| 14            |                 |            |
| 15            |                 |            |
| 16            |                 |            |
| 17            | L glass heating | WT-17 3.0  |
| 18            | Syatem park PWR | RD-100     |
| 19            |                 |            |
| 20            |                 |            |
| 21            | Spot lights PWR | WT-13 2.0  |







| PE 6-968975-1 |                   |           |
|---------------|-------------------|-----------|
| 1             |                   |           |
| 2             |                   |           |
| 3             | R wipe motor park | WH-RF 1.5 |
| 4             |                   |           |
| 5             |                   |           |
| 6             | R wiper motor n1  | WH-RL 1.5 |
| 7             |                   |           |
| 8             |                   |           |
| 9             | R wiper motor n2  | WH-RH 1.5 |
| 10            |                   |           |
| 11            |                   |           |
| 12            |                   |           |
| 13            |                   |           |
| 14            |                   |           |
| 15            |                   |           |
| 16            |                   |           |
| 17            |                   |           |
| 18            |                   |           |
| 19            |                   |           |
| 20            |                   |           |
| 21            |                   |           |

| PF 9-968975-2 |                    |            |
|---------------|--------------------|------------|
| 1             |                    |            |
| 2             |                    |            |
| 3             | M intermittence    | RD-106 1.0 |
| 4             | Washer             | RD-107 1.0 |
| 5             |                    |            |
| 6             | Washer pump        | WH-7+9 1.5 |
| 7             |                    |            |
| 8             |                    |            |
| 9             | R glass heating    | WH-28 3.0  |
| 10            |                    |            |
| 11            |                    |            |
| 12            |                    |            |
| 13            | Flash PWR          | RD-121 1.0 |
| 14            |                    |            |
| 15            | L wiper motor n2   | WH-LH 1.5  |
| 16            | Window heating     | PG-4       |
| 17            | Side wiper n1      | RD-128 1.0 |
| 18            | L wiper motor m1   | WH-LL 1.5  |
| 19            | Side wiper n2      | RD-129 1.0 |
| 20            | L wiper motor park | WH-LF 1.5  |
| 21            |                    |            |


| PG 8-968975-1 |                    |            |
|---------------|--------------------|------------|
| 1             | Brake lights       | RD-112     |
| 2             | Switchs PWR        | RD-166     |
| 3             | Sensor PWR         | RD-077     |
| 4             | Windows heating SW | YE-127     |
| 5             | Brake signal       | YE-064     |
| 6             | Lamp PWR           | RD-167     |
| 7             |                    |            |
| 8             | Clutch control     | BU/RD 0.75 |
| 9             | Steering colm PWR  | RD-185     |
| 10            | Ground lead        | BK-185     |
| 11            |                    |            |
| 12            | Filter heating PWR | RD-082     |
| 13            | Lo beam signal     | YE-119     |
| 14            |                    |            |
| 15            | Air dry PWR        | RD-083     |
| 16            | IFM Back up alarm  | YE-061     |
| 17            | Hi beam signal     | YE-120     |
| 18            | Preaature switch 3 | RD-078     |
| 19            | Back up alarm      | RD-114     |
| 20            | Clearer light      | RD-169     |
| 21            | Dispaly PWR        | RD-096     |

| PH 5-9689747-1 |                    |        |
|----------------|--------------------|--------|
| 1              | Back up lights     | RD-113 |
| 2              | Controller 3 PWR   | RD-045 |
| 3              | Preaature switch 2 | RD-087 |
| 4              |                    |        |
| 5              | Controller 4 PWR   | RD-009 |
| 6              | Controller 1 PWR   | RD-001 |
| 7              | Back up light SW   | YE-126 |
| 8              | Preaature switch 1 | RD-088 |
| 9              | Controller 2 PWR   | RD-047 |
| 10             |                    |        |
| 11             |                    |        |
| 12             | IFM dispaly PWR    | RD-170 |
| 13             |                    |        |
| 14             | Sensor PWR         | RD-171 |
| 15             | Drive handle PWR   | RD-172 |
| 16             |                    |        |
| 17             | Working handle PWR | RD-173 |
| 18             | Brake switch PWR   | RD-133 |

| PJ 7-968975-1 |                      |              |
|---------------|----------------------|--------------|
| 1             | IGN 15+ PWR          | RD-132       |
| 2             | Emergency stop PWR   | RD-117       |
| 3             | Generator PWR        | RD-188       |
| 4             | IGN 15+ PWR          | RD-132       |
| 5             | Clutch control       | BU/RD 0.75   |
| 6             | A/C PWR              | RD-098       |
| 7             | Strobe lights SW     | YE-123       |
| 8             | Clearer light SW     | RD-124       |
| 9             | Eaton neutral signal | YE-085 PJ-18 |
| 10            | Ground lead          | BK-174       |
| 11            |                      |              |
| 12            | Clutch brake         | WH/RD 0.85   |
| 13            | Work lights SW       | YE-125       |
| 14            | Emergency stop NO    | WH-118       |
| 15            | Engine start PWR     | YE-079       |
| 16            |                      |              |
| 17            |                      |              |
| 18            | Eaton neutral signal | YE-085 PJ-9  |
| 19            | Engine IGN 15+       | RD-081       |
| 20            | Strobe lights        | WH-30 2.0    |
| 21            | Engine start signal  | YE-071       |



K01



K04

K05

K06

K07

K08

K17

K22

FS1

K02

FS2


FS3

K15

F61

K03

K16



K09

K10

K11

K12

K13

K14

K18



K23

K19

K24


K20

K25




F41 F42 F43 F44 F45 F46 F47 F48 F49 F50 F51 F52 F53 F54 F55 F56 F57 F58 F59 F60


K21




PJ



PH



PG





PF

D

C

B

A



| A Engine wire harness |                            |            |                 |
|-----------------------|----------------------------|------------|-----------------|
| ITT-A                 | Engine start PWR           | WH 2.0     | w-1             |
| ITT-B                 | Engine ECM PWR             | YE 2.0     | r-3 & r-4       |
| ITT-C                 | Engine IGN 15+             | YE/WH 0.85 | x1-45           |
| ITT-D                 | Filter heating             | BK/WH 2.0  | v-1             |
| ITT-E                 | Air dryer PWR              | GN 2.0     | j-2             |
| ITT-F                 | Clutch brake               | WH/RD 0.85 | g1-3            |
| ITT-G                 | Eaton neutral signal       | OR/WH 0.85 | e-2             |
| ITT-H                 | Clutch switch              | OR/BK 0.85 | r-3             |
| ITT-I                 | Pressure switch 2 PWR      | RD/WH L    | d-1 & e-1 & z-1 |
| ITT-J                 | Pressure switch 1          | RD/WH M    | c-1 & n-2 & p-1 |
| ITT-K                 | Diagnostic PWR             | RD 0.85    | x2-B            |
| ITT-L                 | Generator PWR              | WH/BK 2.0  | k-1             |
| ITT-M                 | Diff lock                  | RD/GN 0.85 | g-3             |
| ITT-N                 | Steer Valve Lock 2         | BU/BK 0.85 | y-2             |
| ITT-O                 | Travel Motor Valve         | GR/RD 0.85 | f-2             |
| ITT-P                 | Pump REV Valve             | YE/RD 0.85 | r-2             |
| ITT-Q                 | Pump FWD Valve             | YE/BU 0.85 | o-2             |
| ITT-R                 | Gearbox Fast Hi/Low switch | BN/BU 0.85 | d-2             |
| ITT-S                 | Rear Diff Lock Feedback    | BK/RD 0.85 | z-2             |
| ITT-T                 | Gearbox Slow Feedback      | BU/YE 0.85 | e-2             |
| ITT-U                 | Gearbox Slow Feedback      | BU/YE 0.85 | e-2             |
| ITT-V                 | Steer Valve Lock 1         | BU/YE 0.85 | x-2             |
| ITT-W                 | FWD Pressure signal        | YE/BK 0.85 | p-2             |
| ITT-X                 | Front diff lock feedback   | BU/WH 0.85 | i-2             |
| ITT-Y                 | Speed signal               | BN 0.85    | c-B             |
| ITT-Z                 | Fuel level signal          | RD/BU 0.85 | m-3             |
| ITT-AA                | Check Engine               | WH/BK 0.85 | x1-43           |
| ITT-AB                | Stop Engine                | WH/YE 0.85 | x1-47           |
| ITT-AC                | Wait Engine                | WH/BU 0.85 | x1-53           |

**KODIAK**

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.


|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01  
 All Others  
 .xx ±0.10  
 .xxx ±0.06  
 .xxx ±0.03

|                              |     |           |            |
|------------------------------|-----|-----------|------------|
| Part Description             |     | Revision  |            |
| <b>Engine wiring harness</b> |     | <b>-0</b> |            |
| Part Number                  |     | Revision  |            |
| <b>550S-0901004</b>          |     | <b>-0</b> |            |
| DRAWN BY                     | JND | DATE      | 01/04/2020 |
| SCALE:                       | 3:2 | WEIGHT:   |            |
| SHEET 1 OF 1                 |     |           |            |

| XS Travel Lock 1 DT06-2S |               |     |
|--------------------------|---------------|-----|
| 1                        | Ground        | B-1 |
| 2                        | Travel Lock 1 | B-7 |



| T Travel Lock 2 DT06-2S |               |     |
|-------------------------|---------------|-----|
| 1                       | Ground        | B-1 |
| 2                       | Travel Lock 2 | B-8 |

| XE Air Pressure |                   |      |
|-----------------|-------------------|------|
| 1               | Pressure switch 3 | B-46 |
| 2               | Air Pressure      | B-39 |

| XK Snow Guide L DT06-2S |              |      |
|-------------------------|--------------|------|
| 1                       | Ground       | B-1  |
| 2                       | Snow Guide L | B-12 |

| XM Gearbox Hight Valve DT06-2S |                     |      |
|--------------------------------|---------------------|------|
| 1                              | Ground              | B-1  |
| 2                              | Gearbox Hight Valve | B-33 |

| XQ Blower UP DT06-2S |           |      |
|----------------------|-----------|------|
| 1                    | Ground    | B-1  |
| 2                    | Blower UP | B-14 |

| XR Plow Float DT06-2S |            |     |
|-----------------------|------------|-----|
| 1                     | Ground     | B-1 |
| 2                     | Plow Float | B-9 |

| XL Snow Guide R DT06-2S |              |      |
|-------------------------|--------------|------|
| 1                       | Ground       | B-1  |
| 2                       | Snow Guide R | B-11 |

| F Plow Float-Switch |                   |      |
|---------------------|-------------------|------|
| 1                   | Sensor PWR        | B-47 |
| 2                   | Plow Float-Switch | B-23 |

| XC Hyd Oil level switch AMP-2S |                      |      |
|--------------------------------|----------------------|------|
| 1                              | Sensor PWR           | B-47 |
| 2                              | Hyd Oil level switch | B-35 |

| XP Blower Down DT06-2S |             |      |
|------------------------|-------------|------|
| 1                      | Ground      | B-1  |
| 2                      | Blower Down | B-13 |

| J Working Pump Sensor AMP-3S |                     |      |
|------------------------------|---------------------|------|
| 1                            | Pressure switch 3   | B-46 |
| 2                            | Working Pump Sensor | B-40 |

| XN Gearbox Low Valve DT06-2S |                   |      |
|------------------------------|-------------------|------|
| 1                            | Ground            | B-1  |
| 2                            | Gearbox Low Valve | B-31 |

| XD Hyd Oil Temperature AMP-2S |                     |      |
|-------------------------------|---------------------|------|
| 1                             | Pressure switch 3   | B-46 |
| 2                             | Hyd Oil Temperature | B-34 |

| XH Steer rear PVG DT06-4S |                   |      |
|---------------------------|-------------------|------|
| 1                         | Rear L (L+Switch) | B-16 |
| 2                         | Ground            | B-1  |
| 3                         | Ground            | B-1  |
| 4                         | Rear R (R+Switch) | B-15 |

| XG Rear Steer Flow Valve DT06-2S |                       |      |
|----------------------------------|-----------------------|------|
| 1                                | Ground                | B-1  |
| 2                                | Rear Steer Flow Valve | B-17 |

| B Hydraulic plug ITT-48 192900-0425 |                       |            |                |
|-------------------------------------|-----------------------|------------|----------------|
| 1                                   | Ground                | BK         |                |
| 2                                   |                       |            |                |
| 3                                   |                       |            |                |
| 4                                   |                       |            |                |
| 5                                   |                       |            |                |
| 6                                   |                       |            |                |
| 7                                   | Travel Lock 1         | WH/GR 0.85 | XS-2           |
| 8                                   | Travel Lock 2         | WH/YE 0.85 | XT-2           |
| 9                                   | Plow Float            | WH/BK 0.85 | XR-2           |
| 10                                  |                       |            |                |
| 11                                  | Snow Guide R          | OR/BL 0.85 | XL-2           |
| 12                                  | Snow Guide L          | OG/WH 0.85 | XK-2           |
| 13                                  | Blower Down           | BN/YE 0.85 | XP-2           |
| 14                                  | Blower UP             | BN/WH 0.85 | XQ-2           |
| 15                                  | Rear R (R+Switch)     | YE/WH 0.85 | XH-4           |
| 16                                  | Rear L (L+Switch)     | YE/BK 0.85 | XH-1           |
| 17                                  | Rear Steer Flow Valve | BU 0.85    | XG-2           |
| 18                                  |                       |            |                |
| 19                                  |                       |            |                |
| 20                                  |                       |            |                |
| 21                                  |                       |            |                |
| 22                                  |                       |            |                |
| 23                                  | Plow Float-Switch     | BU/BK 0.85 | XF-2           |
| 24                                  |                       |            |                |
| 25                                  |                       |            |                |
| 26                                  |                       |            |                |
| 31                                  | Gearbox Low Valve     | GN/BK 0.85 | XM-2           |
| 32                                  |                       |            |                |
| 33                                  | Gearbox Hight Valve   | GN/WH 0.85 | XN-2           |
| 34                                  | Hyd Oil Temperature   | BU/YE 0.85 | XD-2           |
| 35                                  | Hyd Oil level switch  | WH/RD 0.85 | XC-2           |
| 36                                  |                       |            |                |
| 37                                  |                       |            |                |
| 38                                  |                       |            |                |
| 39                                  | Air Pressure          | BU/WH 0.85 | XE-3           |
| 40                                  | Working Pump Sensor   | BU/RD 0.85 | XJ-3           |
| 46                                  | Pressure switch 3     | RD/WH 0.85 | XD-1&XE-2&XJ-1 |
| 47                                  | Sensor PWR            | RD/BN 0.85 | XC-1&XF-1      |
| 48                                  |                       |            |                |

**KODIAK**

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
DIMENSIONS ARE IN INCHES  
Dual dimensions are in mm  
Reference dimensions are in ( )  
TOLERANCES:  
Fractional: ± 1/8"  
Angular: MACH±0.5° BEND±2°  
Machined/Drilled Holes: ±0.01  
All Others  
x.x ±0.10  
x.xx ±0.06  
x.xxx ±0.03

Part Description  
**Hydraulic wiring harness**

Part Number  
**550S-0901005**


Revision  
**0**


DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1







| Intake heating relay |                    |            |        |
|----------------------|--------------------|------------|--------|
| 1                    | Pre-heating GND    | BK/GN 0.85 | ECM-44 |
| 2                    | Pre-heating signal | BK/RD 0.85 | ECM-54 |

Alternator B+ Red 16mm<sup>2</sup>


Starter B+ Red 16mm<sup>2</sup> 950mm


Pre-heating Red 20mm<sup>2</sup> 1150mm





The numbers shown above on this screen correlate directly with the electrical schematic diagram in the maintenance manual. For example, if \_S17 is red, you will know there is a fault in the “Rear Steer flow Valve”.





```

G_WD_EngineSpeed_Potentiometer_Min_Factory : WORD:= 1540;
G_WD_EngineSpeed_Potentiometer_Max_Factory : WORD:= 3188;
G_WD_Decelerate_Padel_Min_Factory : WORD:= 1229;
G_WD_Decelerate_Padel_Max_Factory : WORD:= 4434;
G_WD_EngineSpeed_Padel_Min_Factory : WORD:= 1229;
G_WD_EngineSpeed_Padel_Max_Factory : WORD:= 4434;
G_WD_FrontWheelAngle_Middle_Factory : WORD:= 1841;
G_WD_RearWheelAngle_Middle_Factory : WORD:= 1774;
G_WD_RearWheelAngle_TurnLeftMax_Factory : WORD:= 1572;
G_WD_RearWheelAngle_TurnRightMax_Factory : WORD:= 1970;
END_VAR

```


**VAR\_GLOBAL RETAIN PERSISTENT**

```

G_WD_EngineSpeed_Potentiometer_Min : WORD:= 1540;
G_WD_EngineSpeed_Potentiometer_Max : WORD:= 3188;
G_WD_Decelerate_Padel_Min : WORD:= 1229;
G_WD_Decelerate_Padel_Max : WORD:= 4434;
G_WD_EngineSpeed_Padel_Min : WORD:= 1229;
G_WD_EngineSpeed_Padel_Max : WORD:= 4434;
G_WD_FrontWheelAngle_Middle : WORD:= 1841;
G_WD_RearWheelAngle_Middle : WORD:= 1774;
R_WD_RearWheelAngle_TurnLeftMax : WORD:= 1572;
R_WD_RearWheelAngle_TurnRightMax : WORD:= 1970;
END_VAR

```

# Air System Schematics, models & diagrams



**KODIAK**

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |
|----------|
| MATERIAL |
| ASSEMBLY |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|                                       |                 |                       |         |
|---------------------------------------|-----------------|-----------------------|---------|
| Part Description<br><b>Air System</b> |                 | Revision<br><b>-0</b> |         |
| Part Number<br><b>550S-0700000</b>    |                 | Revision              |         |
| DRAWN BY JND                          | DATE 01/04/2020 | SCALE: 3:2            | WEIGHT: |
|                                       |                 | SHEET 1 OF 1          |         |

# Part II

## Part II Section 1. Maintenance

### 1.1 Maintenance Overview

- For replacement parts, grease and oil, be sure to use genuine Kodiak accessories or products approved by Kodiak.
- Do not mix different types of fluids when changing oil, coolant, or refueling. When changing different types of oil, all old oil must be drained and new oil must be completely filled. At the same time, the oil filter must be replaced.
  - A small amount of residual oil in the lines will not be affected by mixing with new oil
- Unless otherwise specified, the machine is shipped from the factory with the oil and coolant listed in the table below.

| Part                | Brand of oil and fluid | Model of oil and fluid | Consumption per unit (L) |
|---------------------|------------------------|------------------------|--------------------------|
| gearbox             | Mobil                  | 80w-90 GL-5            | 13                       |
| Transfer case       | Mobil                  | 80w-90 GL-5            | 2                        |
| Transmission        | Mobil                  | 80w-90 GL-5            | 17                       |
| Engine coolant      | Mobil                  | Antifreeze - 45 °C     | 54                       |
| engine oil          | Mobil                  | 5W-40 CI-4             | 43                       |
| Axle                | Mobil                  | 80w-90 GL-5            | 26                       |
| Wheel planetary hub | Mobil                  | 80w-90 GL-5            | 4.8                      |
| Wiper               |                        | B-2075-80°C            | 3                        |
| Hydraulic oil       | Mobil                  | DTE 10 EXCEL 32        | 250-300L                 |
| Grease              | Mobil                  | xhp222                 | n/a                      |

## 1.2 Oil

- The high temperature and high pressure of normal use on engine oils, hydraulic oils etc, caused degradation over time. Regular oil changes are required on this vehicle.
- Be sure to only use recommended oils in the operation and maintenance manual that match the maximum and minimum ambient temperature of your working environment.
- In the specified oil change cycle, even if the oil is not dirty, it should be changed.
- Prevent any impurities from entering the lubricating oil such as water, metal particles, dust, etc.)
  - Many faults with major components are caused by impurities.
  - Special care should be taken not to allow any impurities to enter during storage or refueling.
- It is normal and necessary to add oil to maintain a specified amount. Oil levels should be checked daily before and after operation
- Do not mix oils of different grades or grades.
- If the oil in the system is not clean, water or air will enter the oil circuit causing damage.
- When changing the oil, be sure to replace the relevant filter element. In addition, when changing the oil filter element, add clean oil that meets the requirements into the new filter element before installation.
- Use only recommended hydraulic oil. Not doing so may cause the filter element to be plugged
- When changing the hydraulic oil, please remove the residual oil in the pipeline and oil cylinder as much as possible. A small amount of mixing will not cause adverse effects

## 1.3 Hydraulic Oil

- Hydraulic oil is essential to the hydraulic system. It is used to transfer, convert and control energy. At the same time, it also plays the role of lubrication, anti rust, anti-corrosion and cooling of the system. Maintaining clean oil is necessary for proper performance of the hydraulic system and the service life of the hydraulic components.
- The level of oil contamination should ALWAYS stay below NAS9. If it is higher than NAS9, the hydraulic oil must be replaced. The hydraulic oil requirements for the hydraulic system of the equipment are as follows:
  - The original hydraulic oil used is Mobil DTE 10 excel 32.
  - Hydraulic oil may be polluted in the process of transportation and storage.
  - Even newly bought hydraulic oil may look very clean, but in fact it can be "dirty". It must be kept still for several days, filtered and then added to the hydraulic system for use.
  - The oil leaked from the system shall not return to the oil tank without filtration and testing.
  - ISO code number = NAS number

| ISO code number | Number of particles per ml |                     |
|-----------------|----------------------------|---------------------|
|                 | More than                  | Up to and including |
| 22              | 20,000                     | 40,000              |
| 21              | 10,000                     | 20,000              |
| 20              | 5,000                      | 10,000              |
| 19              | 2,500                      | 5,000               |
| 18              | 1,300                      | 2,500               |
| 17              | 640                        | 1,300               |
| 16              | 320                        | 640                 |
| 15              | 160                        | 320                 |
| 14              | 80                         | 160                 |
| 13              | 40                         | 80                  |
| 12              | 20                         | 40                  |
| 11              | 10                         | 20                  |
| 10              | 5                          | 10                  |
| 09              | 2.5                        | 5                   |
| 08              | 1.3                        | 2.5                 |
| 07              | 0.64                       | 1.3                 |

- Please fill the hydraulic oil in strict accordance with the requirements. If the hydraulic oil does not meet the requirements or the hydraulic oil is not replaced in time, any warranty will be voided. Mobil brand hydraulic oil is recommended. If other brands of lubricating oil are used, Kodiak must be consulted prior to use.
- In order to judge the pollution degree of hydraulic oil, the usual evaluation method is to compare the oil to be evaluated with the clean new oil, and observe the difference of oil color, turbidity, dust and sediment. The following is a brief introduction to the simple assessment method used in the field.

| <b>Appearance color</b>          | <b>Smell</b> | <b>Pollution status</b> | <b>Treatment measures</b>                             |
|----------------------------------|--------------|-------------------------|---|
| No change in transparency        | normal       | pollution-free          | Continue to use                                       |
| The transparent color turns pale | normal       | Mix in other oils       | If the viscosity is qualified, it can continue to use |
| Transparent and shiny            | normal       | Mixed with metal chips  | Filter or change oil                                  |
| Transparent with black spots     | normal       | Mixed with impurities   | Filter or change oil                                  |
| Dark brown                       | Smells bad   | Oxidation impurity      | Change all the oil                                    |
| milky white                      | normal       | Mix in air or water     | Change all the oil                                    |

## 1.4 Fuel

- In order to prevent condensation from and forming in the fuel tank, the fuel tank must be filled after daily work.
- The fuel injection pump is a precision component. If the fuel used contains water or dirt, the fuel injection pump will not work normally.
- Drain any water from the fuel system before and 10 minutes after starting the engine.

- If there are any impurities in the fuel tank, flush the fuel tank and fuel system.
- If the engine has run out of fuel or if the filter element is replaced, the air in the system must be purged.
- Always use the fuel specified in the operation and maintenance manual.
- When the fuel is used above the specified temperature, the viscosity will decrease and the output power will decrease.
- When storing or filling fuel, pay special attention not to let impurities in.
- All fuel should be filtered prior to entering the fuel tank.

## **1.5 Coolant for the cooling system**

- Coolant has important anti-corrosion and anti-freezing functions.
- Even in areas where antifreeze is not required, the use of antifreeze is essential.
- The engine is equipped with Mobil-45 Antifreeze. Mobil-45 Antifreeze has excellent anti-corrosion, anti-freezing and cooling characteristics.
- As a basic principle, we do not recommend the use of any other coolant.
- Natural water, such as river water and well water (hard water), contain minerals (calcium, magnesium, etc.), which is easy to scale inside the engine and radiator. Once the engine or radiator has internal scaling, it will be difficult to remove. Due to poor heat exchange and overheating, we do not recommend the use of self-made coolant.
- When using antifreeze, be sure to follow the precautions in this manual.
- Pure antifreeze is flammable and should be kept away from open fire.
- If the engine overheats due to lack of coolant, wait for the engine to cool down before adding coolant.
- If the coolant level is low, it will cause overheating, and as air enters the coolant, it will also cause corrosion problems.

## **1.6 Grease**

- Kodiak recommends Mobil xhp222 grease.
- Grease is used to protect all joints, bearings and shafts.

- Grease not only lubricates sliding surfaces, but it also prevents the mixing of dust and water.
- If any parts appear inflexible or noisy after long-term use, check for abnormal wear. If the part is not damaged, add grease.
- Be sure to use the recommended grease, and follow the recommended replacement cycle and ambient temperature in this manual.
- Before adding new grease, wipe away the old grease.
- Be sure to wipe off the old grease where there is sand and dirt, otherwise the rotating parts will be worn.

## **1.7 Storage of oil and fuel**

- Oil and fuel should be placed indoors to prevent water, dust or other debris from entering.
- When the oil barrel is stored for a long time, the oil barrel should be placed on the side so that the oil filling port of the oil barrel is on the side (to prevent moisture inhalation).
- If the oil drum has to be placed outdoors, cover it with tarpaulin or take other protective measures.

## **1.8 Filter element**

- The filter element is an essential safety component, which can prevent any impurities in the oil circuit and gas circuit from entering the system and causing failure.
- Replace all filter elements regularly. Please refer to the relevant sections of this manual for details.
- When working in harsh conditions, the filter element should be replaced in a short period according to the sulfur content of all lubricating oils and fuels.
- Do not reuse filter elements, always replace it with a new one.

- When replacing the filter element, check whether there are metal particles adsorbed on the old filter element. If metal particles are found, please contact Kodiak or an authorized agent.
- Do not store filters without packaging.

## **1.9 Electrical system maintenance**

- If the electrical equipment is wet or the cladding of the wire is damaged, it may cause an electrical short circuit and lead to machine failure. Do not flush the inside of the electrical cabinet with water. When washing the machine, be careful not to let water enter the electrical components.
- The external electromagnetic interference may cause failure of the control system. When installing radio receivers or other wireless devices, please contact Kodiak or its authorized agent.
- When installing electrical equipment, connect it with a dedicated power connector.
- Do not use mismatched fuses, starting switches or batteries.
- If you need to add new electrical components, please contact Kodiak or its authorized agent BEFORE INSTALLATION.
- Battery charging: vehicle charger can be used to charge the battery (AC 220 V). Please turn off the main power switch before charging to protect the electrical equipment.

## **Section 2: Lubrication**


### **2.1 Manual lubrication**

- There are 12 lubrication points on the head assembly, 56 lubrication points on the chassis making a total of 68 lubrication points.

- When using the grease gun to lubricate the lubricating point, make sure that the clamp head of the grease gun is in good contact with the oil cup (that is, the clamp head can be tightly stuck with the oil cup).
- In case of failure to inject oil, please check whether there is any problem with the chuck, and replace it in time if there is any problem. If there is no problem with the grease gun, please replace the oil cup and then inject oil. If the grease still cannot be injected, it means that the clearance between the pin shaft and the bushing is too small or there are impurities in the clearance between the pin shaft and the bushing. Rotate the pin shaft and inject grease at the same time, so that the grease can be injected.
- Every time lubrication is carried out, the clearance between pin shaft and bushing shall be subject to the overflow of clean grease.


## 2.1.1 Blower head lubrication

- The blower head is a working part, which is used more frequently than other parts. Grease must be injected daily before operation otherwise the bearing or contact surface will be doubly worn leading to parts failure.
- Start the equipment after smearing oil in the chute, and then turn the snow throwing cylinder to make the oil in the chute spread evenly under the push of the slider.
- The following figure shows the specific location of the polishing head lubrication point.




## 2.1.2 Chassis lubrication

- Chassis lubrication is divided into three parts:
  - axle assembly
  - transmission shaft
  - frame assembly.
- The lubricating points of the frame are hidden and the operation space is narrow.
- Please pay attention to all lubrication points.
- **Axle assembly**
  - There are 16 lubrication points in the axle assembly. The figure below shows the location of axle oil filling points.




### Driveline lubrication

- The transmission system assembly has 12 lubrication points. Grease the drivelines as shown below.



- **frame assembly**

- The frame assembly has 28 lubrication points. The figure below shows the number of lubrication points on one side. The number of lubrication points on the other side is the same.



## 2.2 Selection standard of lubricating grease

- The selection of grease is related to speed, working temperature, load and ambient temperature. The grease recommended by Kodiak is Mobil grease xhp222.
- If you want to use a different grease, please contact Kodiak before using.

## Section 3: Wear Items

- Wear items such as diesel filter element, shear bolts and air filter element should be replaced during maintenance or before reaching the wear limit.
- The following table is a list of the main vulnerable parts of the vehicle. In order to use the machine more economically, the vulnerable parts should be replaced correctly.
- For replacement parts, high quality genuine Kodiak parts should be used. When ordering parts, please contact Kodiak or an authorized agent.

| <b>Item</b>         | <b>number</b> | <b>remarks</b>  |
|---------------------|---------------|---|
| Shear bolt          | 6             | Replace as needed   |
| Oil filter          | 1             | —   |
| Oil water separator | 1             | —   |
| Fuel filter element | 2             | Primary filtration and secondary filtration                                   |
| Air filter element  | 2             | Primary filtration and secondary filtration                                   |
| Hydraulic system    | 3             | Return oil filter element, drive pump filter element and hydraulic oil filter |
| Brake disc          | 1             | —   |

## **Section 4: Maintenance Capacity Table**

- Various oils are used according to the maintenance capacity table below. Too much oil may lead to equipment failure, harmful overflow, and too little oil may lead to insufficient lubrication and equipment failure. Please use Kodiak recommended oil when filling oil. The filling capacity is described in Table 4-1 below. The cycle below is every year or 250 hours of operation, whichever comes first.

| Item | Part name           | Brand of oil and fluid | Model of oil and fluid | Consumption per unit (L) | Note   | Maintenance cycle year | remarks                        |
|------|---------------------|------------------------|------------------------|--------------------------|--|------------------------|--------------------------------|
| 1    | gearbox             | Mobil                  | 80w-90 GL-5            | 13                       | Level hole                                     | 1                      | —                              |
| 2    | Transfer case       | Mobil                  | 80w-90 GL-5            | 2                        | Level hole                                     | 1                      | —                              |
| 4    | Transmission        | Mobil                  | 80w-90 GL-5            | 17                       | Level hole                                     | 2                      | —                              |
| 5    | Engine coolant      | Mobil                  | Antifreeze - 45 °C     | 54                       | Liquid level to the middle of oil mirror       | 2                      | Including engine radiator, etc |
| 6    | engine oil          | Mobil                  | 5W-40 CI-4             | 43                       | Between A and F                                | 1                      |                                |
| 7    | Axle                | Mobil                  | 80w-90 GL-5            | 26                       | Liquid level to the bottom of observation port | 1                      | Single bridge 13L              |
| 8    | Wheel planetary hub | Mobil                  | 80w-90 GL-5            | 4.8                      | Liquid level to the bottom of observation port | 1                      | Single wheel 1.2L              |
| 9    | Glass detergent     |                        | B-2075-80 °C           | 3                        | Top up   | —                      |                                |
| 10   | Hydraulic oil       | Mobil                  | DTE 10 EXCEL 32        | 300                      | Liquid level to window 2 / 3                   | 1                      |                                |

## Section 5: Filter elements

All maintenance filter elements are summarized in the table below, along with the steps, maintenance cycle and precautions of replacing filter elements are described in detail in Section 9.

| Item | Description                         | Model        | Manufacturer     | Quantity required | Maintenance cycle                                   |
|------|-------------------------------------|--------------|------------------|-------------------|---|
| 1    | Engine oil filter element           | LF9080       | Cummins          | 1                 | a year  |
| 2    | Oil water separator                 | FS36230      | Cummins          | 1                 | a year  |
| 3    | Primary fuel filter                 | FS36260      | Cummins          | 1                 | a year  |
| 4    | Secondary fuel filtration           | FF5687       | Cummins          | 1                 | a year  |
| 5    | Primary air filter element          | AA2960       | Cummins          | 1                 | One year / 3 times cleaning                         |
| 6    | Secondary air filter element        | AF26434      | Cummins          | 1                 | a year  |
| 7    | Hydraulic oil filter                | PBE0160F010N | Collins          | 1                 | a year  |
| 8    | Hydraulic oil return filter element | FAX-400X20   | Liming hydraulic | 1                 | a year  |
| 9    | Drive pump filter element           | 0009830643   | Linde hydraulic  | 1                 | a year  |
| 10   | Air dryer                           | 4324102412   | Wabco            | 1                 | One year or water discharged from the exhaust valve |

## Section 6: Torque Specifications

- During maintenance and regular use of the equipment, bolts and fasteners need to be replaced. When doing so it is necessary to use the specified torque value. In order to prevent the bolts, nuts, double head studs and other fasteners used in this vehicle from overload damage due to excessive force in the assembly process, and to establish a unified standard for the safe tightening of these fasteners, we have compiled the following tables.

Table 6-1 maximum tightening torque of threaded fasteners (metric system)

| Thread size | Grade                 |       |      |       |      |        |      |       |
|-------------|-----------------------|-------|------|-------|------|--------|------|-------|
|             | 4.8                   |       | 8.8  |       | 10.9 |        | 12.9 |       |
|             | Torque specifications |       |      |       |      |        |      |       |
|             | Nm                    | Lb.ft | Nm   | Lb.ft | Nm   | Lb. ft | Nm   | Lb.ft |
| M1.6        | –                     | –     | 0.20 | 0.15  | –    | –      | 0.20 | 0.15  |
| M2.0        | –                     | –     | 0.25 | 0.20  | –    | –      | 0.45 | 0.30  |
| M2.5        | –                     | –     | 1    | 0.75  | –    | –      | 1    | 0.75  |
| M3.0        | –                     | –     | 1    | 0.75  | –    | –      | 2    | 1.5   |
| M3.5        | –                     | –     | 2    | 1.5   | –    | –      | 3    | 2     |
| M4.0        | –                     | –     | 3    | 2     | –    | –      | 4    | 3     |
| M5.0        | –                     | –     | 5    | 4     | –    | –      | 8    | 6     |
| M6.0        | –                     | –     | 9    | 6     | –    | –      | 13   | 10    |
| M9.0×1.25   | –                     | –     | 21   | 15    | 27   | 20     | 32   | 23    |
| M9.0×1.00   | –                     | –     | 23   | 17    | 29   | 21     | 34   | 25    |

|            |      |      |     |    |      |      |      |      |
|------------|------|------|-----|----|------|------|------|------|
| M10.0×1.50 | –    | –    | 42  | 31 | 54   | 39   | 63   | 46   |
| M10.0×1.25 | –    | –    | 45  | 32 | 57   | 41   | 67   | 48   |
| M12.0×1.75 | –    | –    | 74  | 53 | 94   | 68   | 110  | 80   |
| M12.0×1.25 | –    | –    | 81  | 58 | 103  | 74   | 121  | 87   |
| M14.0×2.00 | –    | –    | 118 | 85 | 151  | 109  | 176  | 127  |
| M14.0×1.50 | –    | –    | 128 | 92 | 163  | 118  | 190  | 137  |
| M16.0×2.00 | 169  | 122  | –   | –  | 234  | 169  | 274  | 197  |
| M16.0×1.50 | 181  | 130  | –   | –  | 250  | 180  | 292  | 211  |
| M19.0×2.50 | 234  | 169  | –   | –  | 323  | 234  | 378  | 273  |
| M19.0×1.50 | 263  | 190  | –   | –  | 363  | 262  | 425  | 307  |
| M20.0×2.50 | 330  | 239  | –   | –  | 457  | 330  | 531  | 386  |
| M20.0×1.50 | 367  | 265  | –   | –  | 507  | 366  | 593  | 423  |
| M22.0×2.50 | 451  | 325  | –   | –  | 623  | 450  | 728  | 526  |
| M22.0×1.50 | 495  | 357  | –   | –  | 684  | 494  | 800  | 577  |
| M24.0×3.00 | 571  | 412  | –   | –  | 790  | 570  | 923  | 667  |
| M24.0×2.00 | 623  | 450  | –   | –  | 861  | 622  | 1007 | 727  |
| M27.0×3.00 | 837  | 605  | –   | –  | 1158 | 836  | 1354 | 977  |
| M27.0×2.00 | 903  | 652  | –   | –  | 1250 | 902  | 1461 | 1055 |
| M30.0×3.00 | 1135 | 820  | –   | –  | 1570 | 1134 | 1835 | 1325 |
| M30.0×2.00 | 1258 | 908  | –   | –  | 1740 | 1256 | 2034 | 1468 |
| M30.0×1.50 | 1300 | 939  | –   | –  | 1799 | 1299 | 2102 | 1516 |
| M36.0×4.00 | 1985 | 1433 | –   | –  | 2745 | 1982 | 3208 | 2317 |
| M36.0×3.00 | 2102 | 1517 | –   | –  | 2907 | 2099 | 3398 | 2453 |

**Note:**

- The maximum tightening torque of standard bolts & nuts in this table is about 75% of the yield limit of material.
- All torque values in the table are relative to lubricated threads. The meaning of "lubrication" here includes the use of thread lubricant, cadmium plating or hardened washer.
- The torque values in the table are the recommended values for general fasteners. In practical application, the allowable tightening load has a variation of  $\pm 10\%$ .

Table 6-2 maximum tightening torque of threaded fasteners (SAE)

| Thread size | Grade                         |       |                               |       |                               |       |                               |       | With 12 point cap screws |       |
|-------------|-------------------------------|-------|-------------------------------|-------|-------------------------------|-------|-------------------------------|-------|--------------------------|-------|
|             | GM 260-m steel<br>SAE grade 2 |       | GM 280-m steel<br>SAE grade 5 |       | GM 290-m steel<br>SAE grade 7 |       | GM 300-m steel<br>SAE grade 8 |       |                          |       |
|             | Torque specifications         |       |                               |       |                               |       |                               |       |                          |       |
|             | Nm                            | Lb.ft | Nm                            | Lb.ft | Nm                            | Lb.ft | Nm                            | Lb.ft | Nm                       | Lb.ft |
| 0.25-20     | 5                             | 4     | 8                             | 6     | 11                            | 8     | 12                            | 9     | 14                       | 10    |
| 0.25-28     | 7                             | 5     | 10                            | 7     | 12                            | 9     | 14                            | 10    | 15                       | 11    |
| 0.31-18     | 11                            | 8     | 18                            | 13    | 22                            | 16    | 24                            | 18    | 27                       | 20    |
| 0.31-24     | 12                            | 9     | 19                            | 14    | 24                            | 18    | 27                            | 20    | 30                       | 22    |
| 0.44-14     | 33                            | 24    | 47                            | 35    | 59                            | 43    | 68                            | 50    | 75                       | 55    |
| 0.44-20     | 37                            | 27    | 54                            | 40    | 68                            | 50    | 79                            | 58    | 87                       | 64    |
| 0.50-13     | 50                            | 37    | 75                            | 55    | 94                            | 69    | 106                           | 78    | 119                      | 88    |
| 0.50-20     | 56                            | 41    | 88                            | 65    | 106                           | 78    | 122                           | 90    | 134                      | 99    |
| 0.56-12     | 75                            | 55    | 108                           | 80    | 136                           | 100   | 156                           | 115   | 171                      | 126   |
| 0.56-18     | 81                            | 60    | 122                           | 90    | 149                           | 110   | 176                           | 130   | 191                      | 141   |

|          |     |     |      |      |       |       |       |       |       |       |
|----------|-----|-----|------|------|-------|-------|-------|-------|-------|-------|
| 0.62-11  | 102 | 75  | 149  | 110  | 190   | 140   | 217   | 160   | 237   | 175   |
| 0.62-18  | 115 | 85  | 169  | 125  | 210   | 155   | 244   | 180   | 270   | 199   |
| 0.75-10  | 176 | 130 | 271  | 200  | 332   | 245   | 380   | 280   | 420   | 310   |
| 0.75-16  | 203 | 150 | 298  | 220  | 366   | 270   | 420   | 310   | 472   | 348   |
| 0.88-9   | 169 | 125 | 434  | 320  | 536   | 395   | 610   | 450   | 679   | 501   |
| 0.88-14  | 190 | 140 | 488  | 360  | 590   | 435   | 678   | 500   | 751   | 554   |
| 1.00-8   | 258 | 190 | 651  | 480  | 800   | 590   | 915   | 675   | 1021  | 753   |
| 1.00-12  | 285 | 210 | 719  | 530  | 881   | 650   | 1003  | 740   | 1119  | 825   |
| 1.00-14  | 285 | 210 | 732  | 540  | 902   | 665   | 1030  | 760   | 1148  | 847   |
| 1.12-7   | 366 | 270 | 800  | 590  | 1132  | 835   | 1302  | 960   | 1447  | 1067  |
| 1.12-12- | 407 | 300 | 902  | 665  | 1274  | 940   | 1451  | 1075  | 1624  | 1198  |
| 1.25-7   | 515 | 380 | 1132 | 835  | 1600  | 1180  | 1830  | 1350  | 2043  | 1507  |
| 1.25-12  | 569 | 420 | 1254 | 925  | 1776  | 1310  | 2034  | 1500  | 2267  | 1672  |
| 1.38-6   | 664 | 490 | 1478 | 1090 | 2095  | 1545  | 2400  | 1770  | 2676  | 1974  |
| 1.38-12  | 759 | 560 | 1688 | 1245 | 2393  | 1765  | 2739  | 2020  | 3056  | 2254  |
| 1.50-6   | 881 | 650 | 1966 | 1450 | 2786  | 2055  | 3186  | 2350  | 3556  | 2623  |
| 1.50-8   | 936 | 690 | 2088 | 1540 | 2962  | 2185  | 3390  | 2500  | 3781  | 2789  |
| 1.50-12  | 990 | 730 | 2217 | 1635 | 3145  | 2320  | 3593  | 2650  | 4010  | 2958  |
| 2.00-8   | –   | –   | –    | –    | 7342  | 5415  | 8406  | 6200  | 9367  | 6909  |
| 2.00-12  | –   | –   | –    | –    | 7687  | 5670  | 8786  | 6480  | 9811  | 7236  |
| 2.25-4.5 | –   | –   | –    | –    | 9701  | 7155  | 11090 | 8180  | 12377 | 9129  |
| 2.25-8   | –   | –   | –    | –    | 10629 | 7840  | 12148 | 8960  | 13566 | 10006 |
| 2.25-12  | –   | –   | –    | –    | 11050 | 8150  | 12636 | 9320  | 14102 | 10401 |
| 2.5-12   | –   | –   | –    | –    | 15280 | 11270 | 17463 | 12880 | 19500 | 14383 |

**Note:**

- The maximum tightening torque of standard bolts & nuts in this table is about 75% of the yield limit of bolt (nut) material.
- The thread specification is "0.25-20", in which 0.25 means the nominal diameter of the thread is 0.25in; 20 means 20 teeth per inch (i.e. pitch), converted into metric system, it is 25.4mm/20 = 1.27mm, i.e. pitch is 1.27mm.
- All torque values in the table are relative to lubricated threads. The meaning of "lubrication" here includes the use of thread lubricant, cadmium plating or hardened washer.
- The tightening torque in the table is the recommended value for general fasteners. In practical application, the tightening load is allowed to change by  $\pm 10\%$ .
- The torque specifications in the table correspond to the material specified in the GM standard. For the material beyond GM standard, you can query table 6-3, first convert it into GM standard material, and then check the torque value.

| Non GM standard materials    |         | Hardness              | GM standard material |
|------------------------------|---------|-----------------------|----------------------|
| Ordinary low carbon steel    | SAE1018 | Rockwell "B" 85 ~ 100 | GM 260-M             |
|                              | SAE1020 |                       |                      |
| Ordinary medium carbon steel | SAE1035 | Rockwell "C" 19 ~ 30  | GM 280-M             |
|                              | SAE1038 |                       |                      |
|                              | SAE1045 |                       |                      |
| Medium carbon alloy steel    | SAE4140 | Rockwell "C" 28 ~ 34  | GM 290-M             |
|                              |         | Rockwell "C" 32 ~ 38  | GM 300-M             |
|                              | SAE8642 | Rockwell "C" 28 ~ 34  | GM 290-M             |
|                              |         | Rockwell "C" 32 ~ 38  | GM3 00-M             |
|                              | SAE5157 | Rockwell "C" 28 ~ 34  | GM 290-M             |
|                              | SAE5147 | Rockwell "C" 32 ~ 38  | GM 300-M             |

**Note:**

- Improper screwdrivers and spanners shall not be used when tightening bolts and nuts. When tightening the nuts of a group of bolts, according to the shape of the connected parts and the distribution of bolts or nuts, tighten them evenly in a certain order (generally 2-3 times) to ensure that all screws or bolts have the same preload. When tightening a group bolts of rectangular arrangement, it should start from the middle and gradually expand and tighten symmetrically to both sides; when tightening the group bolts or nuts of circular or square arrangement, it must be done symmetrically, if there is a locating pin, it should start from the screw or bolt close to the locating pin.
- When a safety wire is used at the bolt head, it shall be threaded and wrapped firmly according to the thread rotation direction. When double nuts are used and adhesive is not used to prevent loosening, thin nuts should be installed first, and then the thick nuts should be tightened with about 80% torque, and then the thick nuts should be tightened with 100% torque.
- If the fastener needs to be replaced, its model should be the same as the original, or a replacement with the same performance as the original should be used. It is not allowed to use substitutes that are inferior to the original quality or inconsistent with the original design, so as to avoid unnecessary losses such as equipment damage or personal injury.
- When a self-locking fastener is removed and reinstalled on the original assembly, it can produce a measurable engagement or torque to provide relocking. Note: every time a self-locking nut is used, its locking function will degrade. In order to ensure the reliability of the self-locking fastener, it is stipulated that the self-locking fastener should only be used once.

Table 6-4 minimum universal disassembly torque of the lock nut

| Thread size | Bolt  |        | Lock nut    |       |             |       |
|-------------|---|--------|-------------|-------|-------------|-------|
|             | Grade   |        |             |       |             |       |
|             | SAE grade 5,<br>SAE grade 8 and<br>ASTM a-574 |        | SAE grade 5 |       | SAE grade 8 |       |
|             | Nm  | Lb. ft | Nm          | Lb.ft | Nm          | Lb.ft |
| 0.25-20     | 0.3   | 3      | 0.4         | 3.5   | 0.5         | 4.5   |
| 0.25-28     | 0.3   | 3      | 0.4         | 3.5   | 0.5         | 4.5   |
| 0.31-18     | 0.6   | 5      | 0.6         | 5.5   | 0.9         | 7.5   |
| 0.31-24     | 0.6   | 5      | 0.6         | 5.5   | 0.9         | 7.5   |
| 0.38-16     | 1.0   | 9      | 1.0         | 9.5   | 1.3         | 11.5  |
| 0.38-24     | 1.0   | 9      | 1.0         | 9.5   | 1.3         | 11.5  |
| 0.44-14     | 1.4   | 12     | 1.4         | 12    | 1.8         | 16    |
| 0.44-20     | 1.4   | 12     | 1.4         | 12    | 1.8         | 16    |
| 0.50-13     | 1.8   | 16     | 1.7         | 15    | 2.3         | 20    |
| 0.50-20     | 1.8   | 16     | 1.7         | 15    | 2.3         | 20    |
| 0.56-12     | 2.5   | 22     | 2.4         | 21    | 3.2         | 28    |
| 0.56-18     | 2.5   | 22     | 2.4         | 21    | 3.2         | 28    |
| 0.62-11     | 3.4   | 30     | 3.1         | 27    | 4.1         | 36    |
| 0.62-18     | 3.4   | 30     | 3.1         | 27    | 4.1         | 36    |
| 0.75-10     | 5.1   | 45     | 4.6         | 41    | 6.1         | 54    |
| 0.75-16     | 5.1   | 45     | 4.6         | 41    | 6.1         | 54    |
| 0.88-9      | 7.3   | 65     | 7.0         | 62    | 9.3         | 82    |
| 0.88-14     | 7.3   | 65     | 7.0         | 62    | 9.3         | 82    |
| 1.00-8      | 9.6   | 85     | 9.5         | 84    | 12.7        | 112   |
| 1.00-12     | 9.6   | 85     | 9.5         | 84    | 12.7        | 112   |
| 1.00-14     | -   | -      | 9.5         | 84    | 12.7        | 9.5   |

## Section 7: Safety Critical Parts

### 7.1 shear bolt

- The shear bolt (Figure 7.1-1) is designed to protect the engine and transmission parts. The shear bolt can cut off the power source when the load exceeds the design load or when the blower is stuck, so as to protect parts of the engine, transfer case and other important assemblies.
- Please refer to Section 8.2 for shear bolt replacement.



Figure 7.1-1 shear bolt


## Section 8: Maintenance Procedures

### 8.1 Daily maintenance

1. Lubrication
  - 1.1. Check the oil quantity of the 68 lubricating ports, and add oil/grease if necessary
2. Electrical system
  - 2.1. Check the working conditions of indicator lights, warning lights and auxiliary electrical equipment
3. Brake system
  - 3.1. Check brake pads and any leaking of brake lines
4. Engine
  - 4.1. Check the oil level and add oil if it is low
  - 4.2. Check for leaks

- 4.3. Check the fan for damage
- 4.4. Check oil temperature and oil pressure gauge reading
5. Fuel system
  - 5.1. Check the fuel system for leaks
  - 5.2. Check the fuel level
  - 5.3. Check the water separator for water accumulation.
6. Cooling system
  - 6.1. Check the coolant level and add coolant if it is low.
  - 6.2. Check the hoses and components for leaks.
  - 6.3. Note: Due to the low temperature environment, the silicone tube expands and contracts with heat, and the coolant may leak from the silicone tube joint. Tightening the clamp can solve the problem.**
7. Air Filter
  - 7.1. Check the air filter indicator
  - 7.2. Check the air intake system for cracks and leaks
8. Hydraulic system
  - 8.1. Check the oil level of the hydraulic oil tank and add oil if it is low
  - 8.2. Check the hydraulic system and components for leakage and the hose for wear or damage
9. Axle
  - 9.1. Visually inspect the tire pressure
  - 9.2. If the axle wheel nut and oil filling / drain plug are loose, retighten them in promptly
  - 9.3. Check the lubricating oil for any leakage
  - 9.4. Check the braking performance and reset. The clearance between the brake lining and drum must be within the range of 0.5-1.5mm. If the clearance exceeds the range or reset is abnormal, please adjust and maintain it in time
10. Heating system


- 10.1. Check whether the ball valve of the heating system pipeline is closed (open when in use, as shown in figure 8.1-1), and whether the heater has leakage.



## 8.2 Shear bolt replacement

1. The shear bolt is an important safety part of the transmission system. It can cut off the power output of the engine and protect the engine when the auger is stuck or the load exceeds the design value due to the inclusion of stones in the snow. There are six shear bolts in the system, two on the left and right flange surfaces of the gearbox (as shown in figure 8.2-1 below), and two on the output shaft (as shown in figure 8.2-2 below). If the auger does not turn and the snow throwing impeller turns, it means that the shear bolt of the transfer case is broken. If the auger and the impeller do not rotate, only the output shaft rotates, it means that there is a problem with the output shear bolt, and the shear bolt can be replaced. The steps to install the shear bolt are as follows:

2. **WARNING: THE shear bolt HAS BEEN DESIGNED AND CHECKED. DO NOT REPLACE WITH ORDINARY BOLTS AS IT WILL LEAD TO EQUIPMENT FAILURE. FAILURE TO USE GENUINE KODIAK SHEAR BOLTS WILL RESULT IN IMMEDIATE VOID OF WARRANTY**
3. When replacing the new shear bolt, if the holes do not align, simply rotate the flange till the holes align and insert the new bolt.
4. Tighten the bolt, but do not over tighten.




9.2-1 Location of gear box shear pin figure

9.2-2 Location of driveline shear pin figure

### 8.3 Wiper Maintenance

1. If the wiper is frozen, do not start the wiper, otherwise the wiper blade will be pulled down or the wiper motor will burn out.
2. First, start the defrosting function, let the warm air melt the thin ice or frost surrounding the wiper. After it has melted, start the wiper.

3. The washer fluid used by the wiper should be suitable for the local temperature environment. We recommend: b-2075, which can withstand low temperatures of  $-80^{\circ}\text{C}$ . The position of wiper filler is shown in figure 8.3-1 below.




8.3.1 Location of wiper fluid filling port inside cab

## 8.4 One month maintenance

### 8.4.1 Clean the primary filter element

1. The dual element air filter consists of a primary element and a secondary element. If properly cleaned and inspected, the primary filter element can be cleaned up to six times. No matter how many times it has been cleaned, it must be replaced after one year. Figure 8.4.1-1 shows the location of the air filter and air filter maintenance indicator. Observe the maintenance indicator. If one of the following conditions occurs, the air filter element should be cleaned or replaced:
  - 1.1. The yellow diaphragm enters the red area.
  - 1.2. Any red is visible (Fig. 8.4.1-1).



1. Air filter indicator 2. Reset key

- Figure 8.4.1-1 location of air filter and maintenance indicator
- The steps to clean or replace the primary filter element are as follows:




Figure 8.4.1-2 structural diagram of air filter  
 1-Filter head cover plate 2-Primary filter element 3-Secondary filter 4-Butterfly buckle 5-Filter body


1. Stop the equipment and hang the "no operation for maintenance" tag;
2. Loosen the butterfly fastener 4 of the air filter (as shown in Fig. 8.4.1-2) and take out the filter head 1;

**ATTENTION:** WHEN CLEANING THE FILTER ELEMENT, ONLY THE PRIMARY FILTER ELEMENT SHOULD BE CLEANED, NOT THE SECONDARY. FAILURE TO DO SO MAY INTRODUCE CONTAMINATION INTO THE ENGINE.

3. Grasp the end face of primary filter element 2 with both hands and gently pull it out.
4. Hold the secondary filter element 3 so that it does not shake or fall out, and clean the inside of the air cleaner housing with a dry cloth.
5. Use dry cloth or compressed air to remove the dust adhering to the vacuum valve.
6. Confirm that there are no cracks in the lip of the vacuum valve. If any crack is found, replace it with a new one.
7. Use compressed air (0.69mpa {7kg / cm<sup>2</sup>}) to blow the dust away from the inside of the primary filter element along the fold. After cleaning the primary filter element three times, the secondary filter element must be replaced.

**ATTENTION:** DO NOT BLOW AIR FROM THE OUTSIDE TO THE INSIDE

8. After cleaning, use a light bulb to illuminate the inside of the primary filter element. If holes or thin areas are found, replace the primary filter element.



9. Install the primary filter element 2 into the air cleaner body 5, and then press the butterfly fastener 4.
10. Press the head of the indicator reset key (2 as shown in figure 8.4.1-1) to remove the blockage and complete the cleaning of the filter element.

#### 8.4.2 Adding coolant

- While operating the equipment, it is necessary to observe the water temperature of the engine. If the water temperature rises suddenly, it is likely there is a coolant shortage in the cooling system. At this time, stop the engine immediately after idling for a period of time, and then wait for the coolant to cool before filling. The position of the filling port is shown in figure 8.4.2-1 below, and the filling steps are as follows:
  1. Stop the engine and hang the "no operation for maintenance" tag;
  2. Cover the pressure cap with a clean cloth and rotate it 90 degrees clockwise;
  3. Use a clean funnel when pouring the coolant. Add it to the middle and upper part of the liquid window;

4. In order to remove the air contained in the coolant, run the engine at low idle for 5 minutes, and then run it at high idle for another 5 minutes;
5. After stopping the engine for about 3 minutes, observe the coolant level, and more if it is still low;
6. Put on the pressure cap and add coolant.




Figure 8.4.2-1 schematic diagram of adding coolant

**WARNING:**

1. AFTER THE ENGINE HAS RUN THERE IS PRESSURE IN THE COOLANT TANK. DO NOT REMOVE THE CAP UNTIL THE TEMPERATURE HAS DROPPED.
2. DO NOT MIX COOLANT TYPES OR BRANDS
3. PURE ANTIFREEZE IS FLAMMABLE
4. ANTIFREEZE IS TOXIC. KEEP AWAY FROM EYES AND SKIN

## **8.5 Six month maintenance**

**IN ADDITION TO THE FOLLOWING ITEMS FIRST PERFORM ALL STEPS FROM THE MONTHLY MAINTENANCE, SECTION 8.4**

### **Cleaning the heat sinks**

1. Check the radiator for these items: corrosion, dirt, grease, insects, leaves and other debris. Clean the radiator if necessary.

2. Compressed air is the preferred method to remove loose debris. Blow the compressed air in the opposite direction to the airflow of the heat sink. Keep the nozzle about 6 mm (0.25 in) away from the heat sink. Slowly move the air nozzle parallel to the radiator duct. This action will remove debris between the tubes.
3. Pressurized water can also be used for cleaning. The maximum water pressure for cleaning must be less than 275 kPa (40 psi). High pressure water is used to soften the sludge. Clean the radiator core from both sides.
4. Use degreaser and steam to remove oil and grease. Clean both ends of the heat sink. Rinse the radiator core with detergent and hot water. Rinse the radiator core thoroughly with clean water.
5. After cleaning, start the engine and raise to a high idle. This step helps to remove debris and dry the tank core. When the engine stops, put a bulb behind the radiator core to check whether the core is clean. Clean again if necessary. Check the radiator for damage. A bent heatsink can be fixed by a "comb knife". Check that these components are in good condition: weldments, mounting brackets, air lines, connections, clamps and seals, and repair if necessary.
6. Note adjust the frequency of cleaning work according to the influence of working environment.:

## **8.6 One year maintenance (or 250 Hours of Operation)**

### **8.6.1 Replace the air filter element (see 8.4.1)**

### **8.6.2 Oil change and oil filter change**

- Tools: Hexagon wrench, one oil filter wrench (07404) larger than 50L container, 43l Mobil 5W-40 ci-4 new oil, one new oil filter lf9080.
- The operation is as follows:
  1. Start the equipment for 10 minutes, then stop the machine and let the engine oil cool down to about 40 °C (high oil temperature will result in low oil viscosity, the debris in the engine can flow out with the engine oil), and hang the "no operation for maintenance" tag.

2. Remove oil drain plug 5 and 4, as shown in figure 8.6.2-1;
3. Open the pressure cap 2 of the oil filling port,
4. Wipe off the residual oil at the drain port and the filling port, tighten the plug of the drain port, and then change the engine oil to filter;
5. Place the oil filter wrench in the middle of the oil cup of oil filter 3, as shown in figure 8.6.2-2, and turn it counterclockwise to remove the old filter element; (be careful not to use too much force)
6. Clean the sealing surface of the mounting base to ensure that all old oil filter gaskets are removed;
7. Fill the new oil filter (If9080) with oil;
8. Lubricate the new O-ring;




Figure 8.6.2-2 oil filter diagram

1-Oil dipstick 2-filling port 3-oil filter element 4,5-oil drain port

9. Install the new filter;
10. When installing a new filter element, do not over tighten it with the filter wrench to prevent damage;




Figure 8.6.2-3 installation drawing of oil filter element

11. Fill the engine oil, and pay attention not to let impurities enter the engine when filling;
12. Start and run the engine at "low idle" for two minutes. This procedure is performed to ensure that there is oil in the lubrication system and that the oil filter is full of oil. Check the oil filter for oil leakage;
13. Stop the engine and wait for at least 10 minutes to make the oil flow back to the oil pan;
14. Take out the oil level gauge and check the oil level. Keep the oil level between "(add)" and "(full)" on the dipstick;
15. Clean the oil filler and install the oil filler pressure cap.




Figure 8.6.2-4 oil dipstick

16. Filter Checking: Unfold the pleats and check for metal debris in the oil filter. Excessive metal debris in the oil filter may indicate early wear or impending failure.

- a. Use a magnet to separate ferrous and non-ferrous metals found in the oil filter element. Ferrous metals indicate wear of steel or cast iron parts of the engine.
- b. Non-ferrous Metals indicate wear of aluminum, brass or bronze parts of the engine. Possible parts involved are: main bearing, connecting rod bearing, turbocharger bearing and cylinder head.
- c. It is normal to find a small amount of metal debris in the oil filter due to normal wear and friction. If excessive debris is found, contact your Kodiak agent for further analysis.





Figure 8.6.2-5 oil filter element

### 8.6.3 Replace the filter element of the oil-water separator

1. Stop the equipment and hang the "no operation for maintenance" tag
2. Prepare a container for waste oil, an oil filter wrench and a new filter element.
3. Rotate the drain valve 6 for 3 turns to drain water;
4. Screw down the water collecting cup (5) for use and do not discard it. Screw down the filter 3 from the base;
5. Replace the O-ring with a new one after installation;
6. Tighten the water collecting cup (5) for  $1 \frac{1}{4}$  -  $1 \frac{1}{2}$  turn;
7. Fill the new filter element (3) with fuel and install it;
8. Lubricate the sealing ring (4) between the new filter and the base;
9. Tighten the new filter to the base plane and then rotate it  $\frac{3}{4}$  turn (it is forbidden to tighten the filter with a wrench)

10. Before pumping oil, loosen the vent bolt, and then press the hand pump (1) to drain the air in the oil pipe;
11. Start the engine and observe whether the filter leaks. If there is no leakage, replace the filter. If there is, check whether the sealing ring is missing or broken.



8.6.3-1 Installation drawing of oil water separator


1. Exhaust button
2. Sealing ring
3. Filter cup
4. Sealing ring
5. Collecting cup
6. Drain valve

#### 8.6.4 Replace the fuel filter

The fuel filter element and the oil-water separator filter element are always replaced together to ensuring that the whole oil system will not have poor filtration due to the mixing of the old and the new.

1. Stop the equipment and hang the "no operation for maintenance" tag
2. Prepare a container for waste oil, an oil filter wrench (07404), fs36260 and ff5687;
3. Remove the primary and secondary fuel filters with a wrench, as shown in figure 8.6.4-1;
4. Remove the old filter element and the old sealing ring at the same time;
5. Check whether the new filter plug is installed in place;
6. Fill the new filter with clean oil;

7. Lubricate the new sealing ring;
8. Pull out the plug;
9. Rotate the new filter to the base sealing surface;
10. Rotate 3 / 4 turn to tighten;
11. After replacing another filter with the above method, start the engine and observe whether the fuel filter leaks. If not, replace the fuel filter.



8.6.4-1 Fuel filter diagram

1. Filter 1, 2. Filter 2

### 8.6.5 Changing oil in the transfer case

1. Stop the equipment, hang the "no operation for maintenance" tag, and chalk the tires;
2. Prepare a spanner, a funnel, a waste oil container and compressed air;
3. Remove plug (2) and use the container to receive the waste oil;
4. After the oil is discharged, open the oil filling port 3, and then blow compressed air from the oil filling port 3 to blow out the residual oil;
5. Plug the oil drain plug (2) and fill the lubricating oil with a funnel. Refer to Chapter 5 for filling capacity, or fill until the oil overflows from the filling port;

6. Start the equipment and observe whether the plug leaks oil. If it leaks oil, tighten it again;
7. It is normal to find a small amount of metal debris in the oil filter due to normal wear and friction. If excessive debris is found, contact your Kodiak agent for further analysis.





Figure 8.6.5-1 location of traveling transfer case  
 1. Vent 2. Oil drain 3. Oil filler



1: Oil inlet cap Oil level cap  
 2: Drain oil cap

## 8.6.6 Changing axle oil




Fig. 8.6.6-1 changing lubricating oil for axle pack

1. Planetary hub oil drain and filling port
2. Axle pack air vent
3. Axle pack lubricating oil filling port
4. Oil drain port

### Changing axle oil

1. Drive the car to a flat position, turn off the engine, hang up the "no operation for maintenance" tag, place it at the start key, and chalk the tires;
2. Remove oil plug (4), catch the waste oil with a container, and open the lubricating oil filling port (3) of the bridge package at the same time to make the waste liquid flow faster;
3. Blow clean compressed air into the oil chamber from port (3) to blow out the residual oil. Clean up the residual oil in port (3) and port (4), replace the oil plug in port (4), to a torque of  $80 \pm 10\text{nm}$ ;
4. Fill lubricating oil with funnel. The model of lubricating oil is Mobil 80w-90 GL-5. Please do not add different types of lubricating oil, fill it to the following figure 8.6.6-2-a,




Figure 8.6.6-2 oil level diagram of axle

### Changing planetary hub oil

5. Start the vehicle, place the hub oil outlet 1 at 6 clock (Fig. 8.6.6-2-b), turn off the engine, and then remove the plug to drain the oil; use a pipe or funnel to drain the waste oil into the container;
6. Start the vehicle, place the hub oil outlet 1 in the 3 clock direction (Fig. 8.6.6-2-c), turn off the engine, and then use a clean funnel to fill in new lubricating oil until it is as shown in Fig. 8.6.6-2-c.

### 8.6.7 Changing hydraulic oil and filter element of hydraulic system

#### A. Changing the hydraulic oil

1. Make sure blower head is resting on the ground to remove any system pressure.
2. Prepare a container larger than 300L for the drain hose to hold the waste oil
3. Remove the plug (2) as shown in Fig. 8.6.7-1, connect the hose, and put the other end into the waste oil container
4. Turn the handle (3) of the ball valve clockwise 90 ° to start the oil discharge. Observe whether the hydraulic oil is emulsified and whether there are a lot of

impurities in the oil. If the oil has deteriorated please clean the oil tank. Some impurities are normal wear of the hydraulic system, if you find a lot of impurities, please contact Kodiak after-sales service personnel.

5. Close handball valve 1 immediately after releasing
6. Tighten plug (2)
7. Add 250-300L hydraulic oil through the hydraulic tank




Figure 8.6.7-1 position of hydraulic oil drain ball valve

1. Ball valve
2. Ball valve outlet
3. Ball valve handle

## B. Change hydraulic oil filter

1. Prepare a waste oil container and a wrench
2. Put the container under the filter element 1 to receive the oil, and use a wrench to open the nut 4, as shown in figure 8.6.7-2;
3. Remove the oil cup (3) and the filter element (2);
4. Replace with a new filter element model: pbe060f010n, please use the model recommended by Kodiak, otherwise the oil resistance is too large or the chemical reaction system may fail;
5. Tighten the bolt (4), clean the residual oil on the surface of the oil cup, and complete the filter element replacement.




Figure 8.6.7-2 location of oil return filter element and hydraulic oil filter

Figure 8.6.7-3 location of hydraulic oil filter

1. Return oil filter element 2. Hydraulic oil filter

### C. Replace oil return filter element

1. Open the filter cover (1) and take out the filter element;
2. Replace with a new filter element;
3. Tighten the filter cover (1);
4. Start the equipment and observe whether the cover plate leaks. If it leaks, tighten it again.




Figure 8.6.7-3 Schematic diagram of hydraulic oil filter element replacement

1. Cover plate of filter element 2. Oil return filter element

#### D. Replace the pump filter element




Figure 8.6.7-4 Pump filter element

1. Remove the filter element with the filter element wrench;
2. Apply an oil film on the washer;
3. Tighten the filter element until the filter mounting surface contacts the flange end of the filter;
4. Use the filter element wrench to further rotate the filter element by 30 ° and tighten it;
5. Start the engine, check for leaks and retighten if necessary.

6. After starting the engine, observe the oil return filter element and hydraulic oil filter for oil leakage at the same time.

### **8.6.8 Changing gearbox oil**

1. Stop the equipment and hang the "no operation for maintenance" tag;
2. Prepare a 14 hexagon wrench, a funnel and a waste oil container larger than 13L;
3. Open the oil port bolt (2) as shown in figure 8.6.8-1, drain oil into the container and open the bolt oil port bolt to let the air in the cavity circulate and speed up the oil flow out;
4. After discharging, use compressed air to blow out debris from the filling port to the oil chamber. Pay attention to the residual oil flying out of the two ports to avoid the residual oil contacting the skin;
5. Observe the composition of the old oil, some filings in the oil is normal wear, if there is a large amount of debris with iron particulates, please contact Kodiak or maintenance agent;
6. Coat the oil drain bolt with 686 sealing glue, and then tighten the bolt;
7. Use funnel drainage to add transfer case gear oil (80w-90) from port 1. Different brands of oil cannot be mixed. Please use the oil recommended by Kodiak and add the oil to the upper part of the window;
8. Fill to the level of port 3. This should be removed and when oil reaches that level, stop filling and replace the plug
9. Apply 686 sealing glue to the bolt 1 & 3, and then tighten the bolt;
10. Start the equipment and let the auger run for 10 minutes to observe whether there is oil leakage in the transfer case. If there is oil leakage, tighten it.




Figure 8.6.8-1 oil port location of gearbox

1. Oil filling port 2. Oil drain port 3. Oil fill level port

### 8.6.9 Replacing the air dryer filter element

1. Important: ensure that the internal pressure of the air dryer is completely removed before replacement;
2. Before installation, grease the sealing ring and threaded sleeve
3. Tighten the dryer by hand (maximum torque: 15N).




Figure 8.6.9-1 location of air dryer

### 8.6.10 Discharge of water and sediment from the fuel tank

Fuel quality is very important for engine performance and service life. Moisture in the fuel can cause excessive wear of the fuel system. Fuel oil will condense after heating and cooling. Water vapor condensation occurs when the fuel flows through the fuel system. Low fuel levels can cause water to condense and accumulate in the fuel tank. Regular draining of the fuel tank and obtaining fuel from reliable sources will help to remove moisture from the fuel.

1. Let the equipment stand for 72 hours to separate impurities and diesel oil;
2. Open the diesel drain plug to drain the fuel, as shown in figure 8.6.10-1,
3. Observe the discharged fuel. If all the discharges are clean, the oil drain can be blocked. If there are many impurities discharged, the fuel tank assembly should be cleaned. See Chapter 8.8.2 for the cleaning steps of the fuel tank.




Figure 8.6.10-1 Fuel tank drain

## **8.7. Two year maintenance**

**IN ADDITION TO THE FOLLOWING ITEMS FIRST PERFORM ALL STEPS FROM THE ONE YEAR MAINTENANCE SECTION 8.6**

### **8.7.1 Changing the coolant**

1. Stop the engine and hang the "no operation for maintenance" tag;
2. Connect the transition hose to the drain valve for drainage;
3. Rotate the handle of the ball valve to 90 ° and put the other end of the hose into the container. Open the pressure cap (1) of the water tank while discharging the coolant;
4. After discharging the coolant, close the ball valve;
5. After discharging the coolant, add new coolant to the window center of the water tank;
6. To remove air from the coolant, run the engine at low idle for 5 minutes, then at high idle for another 5 minutes. Watch the temperature the whole time
7. After stopping the engine for about 3 minutes, observe the coolant level, and fill if it is low;
8. Open the vent plug of the heater (as shown in Fig. 8.7.1-2), and close if part of the coolant overflows;
9. Start the heater, and touch to feel whether there is liquid flow in the inlet and outlet pipes of the heater, and whether the liquid temperature in the water pipe rises slowly. If there is no liquid flow in the heater, please contact Kodiak or the maintenance agent.
10. Clean the residual liquid on the water tank cover to complete the filling of coolant.




Figure 8.7.1-1 Location of water tank ball valve  
1. Pressure cap 2. Drain valve





Figure 8.7.1-2 Location of heater vent plug

### 8.7.2 Changing transmission oil

1. Remove drain plug (2) and use a container to receive the waste oil;
2. Remove oil filler plug (1) to facilitate the removal of oil;
3. After the oil is discharged, tighten the plug (2);
4. Fill the transmission oil with funnel drainage. The oil can be stopped when the oil overflows. Different kinds of oil cannot be mixed. Tighten plug (1).
5. Start the equipment and drive for 10 minutes to observe whether there is oil leakage at the oil port. If there is oil leakage, tighten it again.



8.7.2-1 Location of oil filling and drain port of transmission

1. Oil filling port. 2. Oil drain plug

## Section 9 Miscellaneous

### 9.1 Maintenance before warehousing

As the snow blower is seasonal equipment and has a long waiting time, the equipment must be maintained before it is put into storage. In addition to maintenance according to section 8.1, Kodiak also requires the following points:

1. Clean the whole machine, and touch up paint to avoid rust
2. Lubricate the equipment according to Section 2.1;
3. Start up for 10 minutes after lubrication to confirm that there is no short circuit in the circuit during cleaning. At the same time, run all operations once, so that the grease just added can be lubricated evenly;
4. The equipment should be stored in a dry environment to avoid rust;
5. Turn off the main power supply;
6. Start once a month to lubricate the equipment for 10 minutes. In case of power loss, please charge the equipment in time. The main power supply must be turned to "off" when charging.

## 9.2 Tire Change

Tools: torque wrench, Jack, No.22 socket, etc

1. Park the car on a smooth ground, wedge the tires, and then turn off the engine;
2. Install the jack, use the sleeve to loosen the bolts on the wheel hub, and take off the tire;
3. Install the spare tire. The tire model is 14.00 R24. When tightening the screws, tighten them according to the tightening sequence shown in the figure below (550-600nm) (diagonal preloading). The tire model matches the wheel hub, and the tire with a mismatched model cannot be installed.
4. The tire pressure is 900 kPa.




Figure 9.2-1 Hub mounting torque range and bolt tightening pattern

## 9.3 Belt Replacement

1. Put the square head of the L-type wrench (4316750) into the square hole of the tension pulley, and then press down the wrench. After the tension pulley moves downward, remove the old belt;
2. Install a new belt, belt model: 5580037;
3. Observe whether the V-groove of the belt falls into the pulley groove. If there is no problem with the installation, start the engine. Observe whether the pulley rotation is abnormal.





Figure 9.3-1 tension pulley belt

#### 9.4 Fan Replacement

1. Loosen the fan cover bolt (1);
2. Loosen the motor mounting bracket bolt (2) to take out the motor and fan cover together. If necessary, loosen the motor oil pipe, so that the motor assembly can be moved out more easily;
3. Loosen the locking bolt of the fan and move out the old fan;
4. Replace the fan with a new one, and then tighten the bolt;
5. Install all the components back to the original position, rotate the fan, and then observe whether the blade of the fan reaches the edge of the fan. If not, start the engine to complete the replacement of the fan. Use only OEM parts




9.4-1 Schematic diagram of fan replacement

1. Fan housing bolt. 2. Motor mounting bracket bolt 3. Fan

## 9.5 Battery Replacement

1. First turn off the main power, remove the negative lead (1), and then remove the positive lead (2);
2. Install four batteries, two 12V batteries in series to form a group of 24 V, and then two groups of parallel power supply 24 V, please use the battery model recommended by Kodiak,
3. First install the positive lead (2), and then the negative lead (1). Follow the principle of first install and then remove, and then install and remove first, so as to avoid a short circuit. Do not mix old and new batteries.

9.5-1 Battery connection configuration



# Part III

## Section 1. Safety instructions

Many accidents in the operation, maintenance and repair of machines are caused by non-compliance with basic safety rules or preventive measures. If you recognize all kinds of potential dangerous situations, accidents can often be avoided. All potential dangers must be reported to the staff. It is necessary to train the staff to master the necessary skills and use the tools correctly. Improper operation, lubrication, maintenance or repair of the machine is dangerous and can at minimum cause failure to the equipment and at worst even casualties. You must read and understand the information about the operation, lubrication, maintenance and repair of the machine before you attempt to carry out these works.



### 1.1 Maintenance personnel

Only trained and instructed personnel can operate and maintain the machine.

### 1.2. Risk in Maintenance



- Pressure Release

Make sure all pressure of the hydraulic system is released BEFORE you remove any valve, cylinder, hydraulic connector or valve cover.



- Liquid Penetration

A protective shield must be used while checking for leaks. Liquid ejected under pressure, even from the pinhole, may penetrate human organs, causing serious injury, or even death. If the fluid penetrates the skin, seek medical attention immediately.

- Prevention of Injury

Do not make any adjustments when the machine is running.

- Prevention of burns

At operating temperature, the engine coolant is hot and pressurized. The radiator and all piping to the heater or engine contain hot water and steam. If exposed this can cause serious burns. Hot engine oil and machine parts can also cause personal injury. Avoid

contact with skin. Engine turbocharger, exhaust pipe, muffler, heater and



other parts are all at high temperature. Do not touch them while the engine is running or within 2 hours of operation.

- Prevention of fire and explosion

All fuel, oil, lubricants and some coolant mixtures are flammable. Leakage or spillage on hot surfaces or electrical components can cause a fire. No smoking is allowed in or around the equipment




- Prevention of cuts and pinches

Equipment belts, fans and rotating shafts and all rotating parts may catch hands, feet or clothes when they rotate. Please pay attention to your hands, feet and clothing in any dangerous area during maintenance.



### 1.3. Precautions Before Maintenance

- Place a "do not operate" or similar warning label on the key switch or handle before maintenance and repair of the machine.
- Wear a safety helmet, protective glasses and other protective measures according to the requirements of working conditions.
- Don't wear bulky clothes or jewelry as they may catch on parts of the machine.
- Be familiar with hand signals and who sends them. Accept signals from only one person.
- Do not put maintenance solutions in glass containers.
- Report all items that must be repaired.




### 1.4 Precautions in Maintenance work.

- Before starting the engine or starting the machine, make sure that no one is working on or near the machine.
- Do not start the engine or move any handle if there is a "do not operate" or similar label on the key switch or handle.



- When getting in and out or on and off the machine: Keep hands and feet in three-point contact while climbing (one hand two feet or two hands one foot).
- It is forbidden to jump up and down from the vehicle, and it is not allowed to climb when the machine is running.
- Do not use any operating mechanism as a handrail.
- It is necessary to keep the cab, vehicle suspension ladder and handrail clean, especially when it snows.
- It is necessary to keep the suspension ladder and handrail clean.



## Section 2. Troubleshooting, Assembly and Disassembly

### 2.1 Troubleshooting.

#### Blower head

| Problem   | Cause  | Remedy   |
|---|--|--|
| Snow not throwing                                   | <ul style="list-style-type: none"> <li>• Snow buildup in volute caused by wet or heavy snow, moving too fast,</li> <li>• Very light snow, moving too slow</li> </ul> | <ul style="list-style-type: none"> <li>• Manually clean with a shovel.</li> <li>• Adjust speed to the condition of show</li> </ul> |
| Ribbons not rotating                                | Master or secondary shear flange shear bolts are broken  | Replace shear bolts  |
| Excessive shaking                                   | Buildup of snow or ice on fan blades.  | Manually clear away ice or snow  |
| Ribbons move slowly when transmission is in neutral | Driveline brake worn out or failed   | Replace brake pads or replace braking unit   |

## Engine won't start

| Problem                         | Cause   | Remedy  |
|---------------------------------|---|---|
| Engine won't turn over          | <ul style="list-style-type: none"> <li>• Low battery voltage</li> <li>• Hydrostatic stroker is not in neutral</li> <li>• Gear shifter not in neutral</li> <li>• Start relay, blown fuse</li> <li>• Damaged starter</li> </ul> | <ul style="list-style-type: none"> <li>• Charge battery</li> <li>• Put the hydrostatic stroker</li> <li>• Place gear shifter in neutral</li> <li>• Replace starter relay and fuse</li> <li>• Repair or replace starter</li> </ul> |
| Engine turns but will not start | <ul style="list-style-type: none"> <li>• Low fuel</li> <li>• Air in the fuel lines</li> <li>• Emergency stop switch pressed</li> </ul>  | <ul style="list-style-type: none"> <li>• Add fuel</li> <li>• Bleed the air from the line</li> <li>• Release emergency stop switch</li> </ul>  |

## Vehicle won't move

| Problem            | Cause                  | Remedy   |
|--------------------|------------------------|--|
| Vehicle won't move | Electrical issue       | <ul style="list-style-type: none"> <li>• On the monitor, check the signal output for hydrostatic drive</li> <li>• Check the output current of the controller</li> <li>• Check the circuit of the drive pump, solenoid valve and drive motor solenoid valve</li> <li>• Check the resistance of the drive motor solenoid and valve coil</li> <li>• On the monitor, check the parking brake signal, <ul style="list-style-type: none"> <li>○ foot brake signal,</li> <li>○ emergency stop switch</li> </ul> </li> </ul> |
| Vehicle won't move | Calibration issue      | Re calibrate the min & max in the "settings" tab of the system   |
| Vehicle won't move | Hydraulic system issue | <ul style="list-style-type: none"> <li>• Check driving pump charge pressure</li> <li>• Check drive pump pressure</li> <li>• Check for hydraulic fluid leakage</li> </ul>   |

|                    |                   |   |
|--------------------|-------------------|---|
| Vehicle won't move | Mechanical reason | <ul style="list-style-type: none"> <li>• Check pump driveline</li> <li>• Check air pressure to make sure parking brake can release</li> </ul> |
|--------------------|-------------------|---|

## Transmission

| Problem                                       | Cause   | Remedy   |
|---|---|--|
| Clutch won't engage or disengage, no shifting | <ul style="list-style-type: none"> <li>• Damaged clutch solenoid valve</li> <li>• Clutch plates worn out</li> </ul> | <ul style="list-style-type: none"> <li>• Replace clutch solenoid valve</li> <li>• Check for damaged wiring</li> <li>• Replace clutch pads</li> </ul> |
| Clutch won't engage or disengage, no shifting | Insufficient clutch air pressure, resulting in the shift booster not working  | Check the air pressure on the display (>0.6Mpa)  |
| Can't select gear, or will not disengage      | <ul style="list-style-type: none"> <li>• Damaged cable</li> <li>• Insufficient cable travel</li> </ul>              | <ul style="list-style-type: none"> <li>• Replace the cable</li> <li>• Adjust the shift cable</li> </ul>  |

## Blower head hydraulic

| Problem  | Cause  | Remedy  |
|--|--|---|
| BLowerhead lift, volute rotations, floating function failure | Controller output current is abnormal        | You can check whether the controller has output by checking the IO interface of the display screen. Gray means no output, green means normal output, and red means line failure or solenoid valve coil failure. |
| same   | Damaged working pump for pressure or leakage | Fix pump or leakage   |
| same   | Damaged solenoid valve                       | <ul style="list-style-type: none"> <li>• Replace solenoid valve</li> </ul>  |

## Front Axle

| Problem                      | Cause                     | Remedy  |
|------------------------------|---------------------------|---|
| Front wheels do not turn     | Steering pressure too low | <ul style="list-style-type: none"> <li>• Check system pressure,</li> <li>• check for leakage</li> </ul>                                   |
| Steering system making noise | Mechanical failure        | <ul style="list-style-type: none"> <li>• Check grease point for abnormal wear</li> <li>• Check all linkages in steering system</li> </ul> |

## Rear Axle

| Problem                            | Cause                                 | Remedy  |
|------------------------------------|---------------------------------------|---|
| Wheels do not turn                 | Controller output current is abnormal | You can check whether the controller has output by checking the IO interface of the display screen. Gray means no output, green means normal output, and red means line failure or solenoid valve coil failure. |
| same                               | Damaged joystick                      | Replace the joystick. If you need to realign the rear wheels, this can be done manually with the valve in the engine compartment  |
|                                    | Steering system pressure too low      | <ul style="list-style-type: none"> <li>• Check system pressure,</li> <li>• check for leakage</li> </ul>   |
| Rear Steer won't engage on monitor | Transfer case in high (Rabbit)        | Set transfer case to low (tortoise)   |

## Transfer case

| Problem  | Cause                                     | Remedy  |
|--|---|---|
| Transfer case cannot switch between high and low | Controller output current is abnormal     | You can check whether the controller has output by checking the IO interface of the display screen. Gray means no output, green means normal output, and red means line failure or solenoid valve coil failure. |
| same   | Physical switch damaged or wiring damaged | Check wiring on switch  |

|      |                    |                       |
|------|--------------------|-----------------------|
| same | Mechanical failure | Service transfer case |
|------|--------------------|-----------------------|

## Air system

| Problem                        | Cause  | Remedy   |
|--------------------------------|--|--|
| Low system air pressure        | <ul style="list-style-type: none"> <li>• Air leak</li> <li>• Sensor failure</li> </ul>   | <ul style="list-style-type: none"> <li>• Replace or fix the line with the leak</li> <li>• Replace the air pressure sensor</li> </ul>                             |
| Brake system has water         | <ul style="list-style-type: none"> <li>• Air dryer failure</li> <li>• Air tank with water</li> </ul>   | <ul style="list-style-type: none"> <li>• Change air dryer filter</li> <li>• Replace air dryer</li> <li>• Drain air tank</li> </ul>                               |
| Brakes are sluggish            | <ul style="list-style-type: none"> <li>• System leak</li> <li>• Pressure is too low</li> <li>• Brake clearance too big</li> </ul>  | <ul style="list-style-type: none"> <li>• Fix leaks</li> <li>• Check system pressure</li> <li>• Adjust brake clearance</li> </ul>                                 |
| Axle differential lock failure | <ul style="list-style-type: none"> <li>• System air pressure too low</li> <li>• Differential lock electromagnet damaged</li> <li>• Differential lock switch wires disconnected or damaged</li> </ul> | <ul style="list-style-type: none"> <li>• Check air system</li> <li>• Replace the differential lock solenoid</li> <li>• Replace switch or repair wires</li> </ul> |

## System communication Failure

| Problem               | Cause                            | Remedy  |
|-----------------------|----------------------------------|---|
| Communication failure | Engine communication failure     | <ul style="list-style-type: none"> <li>• Check the ECM</li> <li>• Check for loose or damaged wires</li> <li>• Check the resistance of the CAN-BUS line</li> </ul>                                       |
| Same                  | Joystick communication failure   | <ul style="list-style-type: none"> <li>• Check the joystick power supply</li> <li>• Check wiring</li> <li>• Check the resistance of the CAN-BUS line</li> </ul>   |
| Same                  | Front or rear steer comm failure | <ul style="list-style-type: none"> <li>• Check the front and rear axle steering angle sensor</li> <li>• Check for loose or damaged wires</li> <li>• Check the resistance of the CAN-BUS line</li> </ul> |

## Battery charging failure


| Problem                    | Cause  | Remedy  |
|----------------------------|--|---|
| Alternator not charging    | <ul style="list-style-type: none"> <li>• Damaged alternator</li> <li>• Alternator fuse blown</li> <li>• Alternator loose or damaged wires</li> </ul> | <ul style="list-style-type: none"> <li>• Replace or repair alternator</li> <li>• Replace fuse</li> <li>• Fix wires</li> </ul>   |
| Battery not holding charge | <ul style="list-style-type: none"> <li>• Damaged battery</li> <li>• Battery disconnected</li> <li>• Master disconnect failure</li> </ul>             | <ul style="list-style-type: none"> <li>• Visually inspect the battery for damage.</li> <li>• Test battery</li> <li>• Check wiring</li> <li>• Replace master disconnect</li> </ul> |

## Water system Failure

| Problem  | Cause   | Remedy  |
|--|---|---|
| Water temperature alarm                                    | <ul style="list-style-type: none"> <li>• Insufficient cooling</li> <li>• Damaged fan</li> <li>• Coolant level sensor failure</li> </ul> | <ul style="list-style-type: none"> <li>• Check coolant level, add if needed</li> <li>• Replace fan</li> <li>• Replace sensor</li> </ul>                             |
| Pipeline leaks   | <ul style="list-style-type: none"> <li>• Loose clamps</li> <li>• Ruptured silicone tube</li> </ul>                                      | <ul style="list-style-type: none"> <li>• Tighten clamps</li> <li>• Replace silicone tubes</li> </ul>  |
| Water temperature under load operation is lower than 60 °C | Engine thermostat is broken   | Contact Kodiak or Cummins for replacement thermostat  |
| No heat in cab   | <ul style="list-style-type: none"> <li>• Ball valve not open</li> <li>• Check coolant lines for damage</li> </ul>                       | <ul style="list-style-type: none"> <li>• Open ball valve</li> <li>• Replace damaged lines</li> <li>• Check vent lines in console for blockage or kinking</li> </ul> |
| Heater exhausts is black                                   | <ul style="list-style-type: none"> <li>• Heater carbon deposits</li> <li>• Exhaust pipe blocked</li> </ul>                              | <ul style="list-style-type: none"> <li>• Repair or replace heater</li> <li>• Check if the intake pipe is blocked</li> </ul>   |

# Part IV

| Num | Part Num.        | Description              | Quantity |
|-----|------------------|--------------------------|----------|
| 1   | 550S-1001100     | Ree-44-108-WLD-Left      | 1        |
| 2   | 550S-1001848     | Moline Bearing           | 2        |
| 3   | 550S-1001497     | Bearing Shim             | 2        |
| 4   | 550S-1001742     | PF-Side-Shim             | 2        |
| 5   | 550S-1001078     | Cutter                   | 1        |
| 6   | 550S-1002060     | Shoes Assembly           | 2        |
| 7   | 550S-1002000     | Plow Frame Weldment      | 1        |
| 8   | 550S-1004820     | Fan Back with bade mount | 1        |
| 9   | 550S-1002600     | Connecting Arm Assembly  | 1        |
| 10  | 550S-1008622     | Left Side Cutter         | 1        |
| 11  | 550S-1006130     | Slid Tube Slug Weldment  | 1        |
| 12  | K01120 Or K90013 | Volute Cylinder          | 1        |
| 13  | 550S-1008212     | Side Cutter Support      | 1        |
| 14  | 550S-1005100     | Volut Weldment           | 1        |
| 15  | 550S-1008211     | Side Cutter Plate        | 1        |
| 16  | 550S-1008213     | Side Cutter Support      | 1        |
| 17  | 550S-1008621     | Right Side Cutter        | 1        |
| 18  | 550S-1003666     | Press Plate              | 6        |
| 19  | 550S-1003665     | Flap                     | 3        |
| 20  | 550S-1003700     | Ree-44-108-WLD-Right     | 1        |
| 21  | 550S-1001860     | Gear Box                 | 1        |
| 22  | 550S-1003416-1   | Volute Ring              | 3        |
| 23  | 550S-1006310     | Fan Blade                | 4        |
| 24  | 550S-K00608      | Flange                   | 2        |
| 25  | 450S-K10601-A-1  | Input-GB-ASM             | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE


|          |
|----------|
| MATERIAL |
| ASSEMBLY |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional  $\pm 1/8"$   
 Angular: MACH  $\pm 0.5^\circ$  BEND  
 Machined/Drilled Holes:

All Others  
 x.x  $\pm 0.10$   
 x.xx  $\pm 0.06$   
 0.03

|                                     |  |                              |  |
|-------------------------------------|--|------------------------------|--|
| Part Description<br>Blower Assembly |  | Revision<br>-0               |  |
| Part Number<br>550S-1001000-1       |  | DRAWN BY JND DATE 01/04/2020 |  |
| SCALE: 3:2                          |  | WEIGHT:                      |  |
| SHEET 1 OF 1                        |  |                              |  |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|           |  |
|-----------|--|
| MATERIAL: |  |
| ASSEMBLY: |  |





UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|                                     |                    |                |        |
|-------------------------------------|--------------------|----------------|--------|
| Part Description<br>Blower Assembly |                    | Revision<br>-0 |        |
| Part Number<br>550S-1001000-2       |                    |                |        |
| DRAWN BY<br>JND                     | DATE<br>01/04/2020 | SCALE<br>3:2   | WEIGHT |
|                                     |                    | SHEET 1 OF 1   |        |

| Num | Part Num.    | Description        | Quantity |
|-----|--------------|--------------------|----------|
| 1   | 550S-1002327 | End Ring           | 4        |
| 2   | M14X45-P1.5  | Bolt               | 40       |
| 3   | M14-P1.5     | Bolt               | 40       |
| 4   | 550S-1002320 | RE-44-108-WLD-LEFT | 1        |
| 5   | 550S-1002310 | FL-44-108-WLD-LEFT | 4        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DO NOT SCALE DRAWING

MATERIAL

ASSEMBLY

UNLESS OTHERWISE SPECIFIED  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractions: 1/8"  
 Angular: MACH ±0.5° BEND ±2°  
 Machined/Drilled Holes: ±0.01

All Others:  
 xx ±0.10  
 xxx ±0.06  
 xxxd ±0.03

Part Description  
 Ree-44-108-WLD-Left

Part Number  
 550S-1001100





Revision  
 -0

DRAWN BY JND DATE 01/04/2021

SCALE: 3/2 WEIGHT:

SHEET 1 OF

| Num | Part Num.    | Description         | Quantity |
|-----|--------------|---------------------|----------|
| 1   | 550S-1002327 | End Ring            | 4        |
| 2   | M14X45-P1.5  | Bolt                | 40       |
| 3   | M14-P1.5     | Bolt                | 40       |
| 4   | 550S-1002330 | RE-44-108-WLD-RIGHT | 1        |
| 5   | 550S-1002340 | FL-44-108-WLD-RIGHT | 4        |



KODIAK


PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|                      |  |
|----------------------|--|
| DO NOT SCALE DRAWING |  |
| MATERIAL             |  |
| ASSEMBLY             |  |

UNLESS OTHERWISE SPECIFIED  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractions: 1/8"  
 Angular: MACH ±0.5° BEND ±2°  
 Machined/Drilled Holes: ±0.01  
 All Others:  
 xx ±0.10  
 xxx ±0.06  
 xxxd 0.03

|                  |     |                      |            |
|------------------|-----|----------------------|------------|
| Part Description |     | Ree-44-108-WLD-Right |            |
| Part Number      |     | 550S-1003700         |            |
| Revision         |     | -0                   |            |
| DRAWN BY         | JND | DATE                 | 01/04/2021 |
| SCALE:           | 3/2 | WEIGHT:              |            |
| SHEET 1 OF       |     |                      |            |

| Num | Part Num.     | Description               | Quantity |
|-----|---------------|---------------------------|----------|
| 1   | 550S-1003210  | support tube assembly     | 1        |
| 2   | 550S-1003232  | pad connecting shaft      | 1        |
| 3   | Q401B30       | flat washers              | 1        |
| 4   | Q5000570      | cotter pin                | 1        |
| 5   | 550S-1003220  | fixed seat                | 1        |
| 6   | 550S-1006123  | adjusting washer          | 2        |
| 7   | 550S-1003240  | sliding shoe support base | 1        |
| 8   | Q218B16110T32 | hexagon socket bolts      | 4        |
| 9   | M16x1.5       | anti-separation nut       | 4        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.


|          |
|----------|
| MATERIAL |
| ASSEMBLY |

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractional  $\pm 1/8"$   
 Angular:  $MACH \pm 0.5^\circ$  BEND  
 Machined/Drilled Holes:  
 All Others  
 x.x  $\pm 0.10$   
 x.xx  $\pm 0.06$   
 0.03

|                  |     |              |            |
|------------------|-----|--------------|------------|
| Part Description |     | Revision     |            |
| Bootship         |     | -0           |            |
| Part Number      |     | 550S-1002060 |            |
| DRAWN BY         | JND | DATE         | 02/29/2024 |
| SCALE:           | 1:5 | WEIGHT:      |            |
|                  |     | SHEET 1 OF 1 |            |

| Num | Part Num.     | Description               | Quantity |
|-----|---------------|---------------------------|----------|
| 1   | 550S-1003232  | pad connecting shaft      | 1        |
| 2   | Q401B30       | flat washers              | 1        |
| 3   | Q5000570      | cotter pin                | 1        |
| 4   | 550S-1003220  | fixed seat                | 1        |
| 5   | 550S-1006123  | adjusting washer          | 2        |
| 6   | 550S-1003240  | sliding shoe support base | 1        |
| 7   | Q218B16110T32 | hexagon socket bolts      | 4        |
| 8   | M16x1.5       | anti-separation nut       | 4        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |                      |
|----------|----------------------|
| MATERIAL | DRAWING NOT TO SCALE |
| ASSEMBLY |                      |


UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional ± 1/8"  
 Angular: MACH ± 0.5° BEND  
 Machined/Drilled Holes:

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 0.03

|                  |              |         |              |
|------------------|--------------|---------|--------------|
| Part Description | Skipper      |         |              |
| Part Number      | 550S-1002050 |         |              |
| Revision         | -0           |         |              |
| DRAWN BY         | JND          | DATE    | 02/29/2024   |
| SCALE:           | 1:5          | WEIGHT: |              |
|                  |              |         | SHEET 1 OF 1 |

| Num | Part Num.     | Description               | Quantity |
|-----|---------------|---------------------------|----------|
| 1   | 550S-1006123  | adjusting washer          | 2        |
| 2   | 550S-1003240  | sliding shoe support base | 1        |
| 3   | Q218B16110T32 | hexagon socket bolts      | 4        |
| 4   | M16x1.5       | anti-separation nut       | 4        |



KODIAK


PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |                      |
|----------|----------------------|
| MATERIAL | DRAWING NOT TO SCALE |
| ASSEMBLY |                      |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractional ± 1/8"  
 Angular: MACH ± 0.5° BEND  
 Machined/Drilled Holes:  
 All Others  
 x.x ±0.10  
 x.xx ±0.06  
 0.03

|  |                    |                |        |
|--|--------------------|----------------|--------|
| Part Description<br>Sliding shoe base assembly |                    | Revision<br>-0 |        |
| Part Number<br>550S-1003250                    |                    |                |        |
| DRAWN BY<br>JND                                | DATE<br>02/29/2024 | SCALE<br>1:5   | WEIGHT |
|  |                    | SHEET 1 OF 1   |        |

| Num | Part Num.          | Description      | Quantity |
|-----|--------------------|------------------|----------|
| 1   | 450S-K00539(-1)    | Volute Guide     | 1        |
| 2   | 450S-K00538(-0)    | Moline Bearing   | 2        |
| 3   | M20X80             | Bolt             | 8        |
| 4   | Ø20                | Washer           | 8        |
| 5   | Ø20                | Spring Washer    | 8        |
| 6   | M20                | Nut              | 8        |
| 7   | 550S-1003160       | Frame Bottom     | 1        |
| 8   | 550S-0300475       | Key              | 2        |
| 9   | 450S-K03167(-2)    | Shaft            | 1        |
| 10  | 450S-K01415 (-0) G | Input Flange     | 1        |
| 11  | M10X25-P1.5        | Bolt             | 8        |
| 12  | Ø10                | Washer           | 10       |
| 13  | Ø10                | Spring Washer    | 10       |
| 14  | 450S-P2A347-1(-0)G | Flange           | 1        |
| 15  | K00002             | Shear Pin        | 2        |
| 16  | Ø12                | Spring Washer    | 2        |
| 17  | M12X1.25           | Bolt             | 2        |
| 18  | K00679             | Seal             | 1        |
| 19  | 450S-P2A391-3(-0)G | Shear Pin Flange | 1        |
| 20  | K00678             | Bearing          | 1        |
| 21  | Q43150             | Snap Ring        | 1        |
| 22  | Q130110            | Snap Ring        | 1        |
| 23  | M12X35-P1.75       | Bolt             | 2        |
| 24  | Ø12                | Washer           | 2        |
| 25  | Ø12                | Spring Washer    | 2        |
| 26  | 550S-1007166       | Cap              | 1        |
| 27  | 550S-1007168       | Cap              | 1        |
| 28  | M10*30-P1.5        | Washer           | 2        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

MATERIAL \_\_\_\_\_

ASSEMBLY \_\_\_\_\_


UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:

All Others:  
 xx ±0.10  
 xxx ±0.06  
 0.03

|                                  |                    |                |         |
|----------------------------------|--------------------|----------------|---------|
| Part Description<br>Input-GB-ASM |                    | Revision<br>-0 |         |
| Part Number<br>450S-K10601-A-1   |                    | Revision<br>-0 |         |
| DRAWN BY<br>JND                  | DATE<br>01/04/2020 | SCALE: 3:2     | WEIGHT: |
|                                  |                    | SHEET 1 OF 1   |         |

| Num | Part Num.          | Description                          | Quantity |
|-----|--------------------|--------------------------------------|----------|
| 1   | 550S-K04239        | Cab Support                          | 1        |
| 2   | 550S-K07223        | Transmission Assembly                | 1        |
| 3   | K550S-K04308(-1)   | Rear Leaf Spring Support             | 2        |
| 4   | 550S-K04353(A0)    | Right Rear Leaf Spring Front Mount   | 1        |
| 5   | K550S-0400040      | Leaf Spring Right Rear Support       | 1        |
| 6   | 550S-K07632        | Pump Support 1                       | 1        |
| 7   | 550S-K05571(-1)    | Pump Support 2                       | 1        |
| 8   | 450S-K04170(-0)    | Pump Drive Assembly                  | 1        |
| 9   | HPV02-105L-E1D2    | Drive Pump                           | 1        |
| 10  | PV_JR_L_S45B_PC_21 | Work Pump                            | 1        |
| 11  | KP30.31S0          | Steering Pump                        | 1        |
| 12  | 550S-K07632        | Pump Mount                           | 1        |
| 13  | 550S-K05004        | Right Frame                          | 1        |
| 14  | 550S-K05003        | Left Frame                           | 1        |
| 15  | 450S-K05040(A0)    | Bumper                               | 1        |
| 16  | 550S-0104040       | Rear Cross Weldment                  | 1        |
| 17  | 550S-0104045       | Rear Cross Mount2                    | 2        |
| 18  | 550S-0104044       | Rear Cross Mount1                    | 2        |
| 19  | K550S-040030       | Spring Hanger upper Weldment         | 1        |
| 20  | 450S-K04309(-1)    | Spring Hanger Lower Weldment         | 4        |
| 21  | K550S-K04346(-0)   | Right Rear Leaf Spring Front Support | 1        |
| 22  | HDZ13T341526009    | Front Axle                           | 1        |
| 23  | HDZ13T341526010    | Rear Axle                            | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |  |
|----------|--|
| MATERIAL |  |
| FINISH   |  |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 .xx ±0.10  
 .xxx ±0.06  
 .xxxx ±0.03

Part Description

Chassis Assembly

Part Number

550S-0101000-1

Revision


-0

DRAWN BY: JND DATE: 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|           |  |
|-----------|--|
| MATERIAL: |  |
| ASSEMBLY: |  |


UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|   |                    |                       |
|---|--------------------|-----------------------|
| Part Description<br><b>Chassis Assembly</b> |                    | Revision<br><b>-0</b> |
| Part Number<br><b>550S-0101000-2</b>        |                    |                       |
| DRAWN BY<br>JND                             | DATE<br>01/04/2020 | SCALE: 3:2            |
| WEIGHT:                                     |                    | SHEET 1 OF 1          |

| Num | Part Num.                | Description               | Quantity |
|-----|--------------------------|---------------------------|----------|
| 1   | TN4313LY-3513015K        | Air Tank                  | 1        |
| 2   | sc2-mimed-4120009        | Valve Bank                | 1        |
| 3   | PVG32-1                  | Danfoss Valve             | 1        |
| 4   | EPC102CN-P21F40-G06-24DD | Flow Control Valve        | 1        |
| 5   | PBF0160F010NB16N         | Hydraulic Pressure Filter | 1        |
| 6   | TV-12                    | Thermostat                | 1        |
| 7   | TN4313LY-3513015K        | Air Tank                  | 2        |
| 8   | 9325000610               | Air Dryer                 | 1        |
| 9   | 6-QW-180                 | Battery                   | 4        |
| 10  | FS36230                  | Fuel And Water Separator  | 1        |
| 11  | HWC3-24V10A              | Charger                   | 1        |
| 12  | EC102CN-P25F76-G06-24DD  | Lock Valve                | 2        |
| 13  | K9735000000              | Quick Relief Valve        | 1        |
| 14  | K04398                   | Lift Cylinder             | 2        |
| 15  | 22004-3                  | Isolator                  | 6        |
| 16  | 450S-K04507(A0)          | Hitch                     | 2        |
| 17  | 4722720230               | Air Valve Bank            | 1        |
| 18  | RV-DN12-G1/2             | Check Valve               | 1        |
| 19  | H73-3721010              | Horn                      | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

MATERIAL: \_\_\_\_\_  
 ASSEMBLY: \_\_\_\_\_

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ± 0.5° BEND ± 2°  
 Machined/Drilled Holes: ± 0.01

All Others  
 x.x ± 0.10  
 x.xx ± 0.06  
 x.xxx ± 0.03

Part Description

Chassis Component Assembly

Part Number

550S-0103000-1

Revision

-0


DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1



KODIAK



PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|  |  |   |  |   |  |
|--|--|---|--|---|--|
| DRAWING NOT TO SCALE                                 |  | UNLESS OTHERWISE SPECIFIED:<br>DIMENSIONS ARE IN INCHES<br>Dual dimensions are in mm<br>Reference dimensions are in ( ) |  | Part Description<br><b>Chassis Component Assembly</b> |  |
| MATERIAL:<br>_____<br>ASSEMBLY:<br>_____             |  | TOLERANCES:<br>Fractional: 1/8"<br>Angular: MACH±0.5° BEND±2°<br>Machined/Drilled Holes: ±0.01                          |  | Part Number<br><b>550S-0103000-2</b>                  |  |
| All Others<br>x.x ±0.10<br>x.xx ±0.06<br>x.xxx ±0.03 |  | DRAWN BY: JND DATE: 01/04/2020  |  | Revision<br>-0  |  |
|  |  | SCALE: 3:2  |  | WEIGHT:   |  |
|  |  |   |  | SHEET 1 OF 1  |  |

| Num | Part Num.                                  | Description              | Quantity | Num | Part Num.      | Description       | Quantity |
|-----|--|--------------------------|----------|-----|----------------|-------------------|----------|
| 1   | 385/65R22.5-20PR AGC28                     | Tire                     | 4        | 19  | H150A22115AZF3 | Lug Nut           | 40       |
| 2   | 22111045                                   | Wheel                    | 4        | 20  | M22            | Bolt              | 40       |
| 3   | ∅410 × 180                                 | Brake chamber (Left)     | 2        | 21  | HD95009440007  | Brake Pad         | 8        |
| 4   | YK04159,-0 L                               | Leaf Spring              | 2        | 22  | K06672         | Steering Cylinder | 4        |
| 5   | YK04160,-0 L                               | Overload Spring Left     | 2        |     |                |                   |          |
| 6   | HDZ13T341526009                            | Front Axle               | 1        |     |                |                   |          |
| 7   | YK04159,-0 R                               | Left Spring Right        | 2        |     |                |                   |          |
| 8   | YK04160,-0 R                               | Overload Spring Right    | 2        |     |                |                   |          |
| 9   | ∅410 × 180                                 | Brake chamber (Right)    | 2        |     |                |                   |          |
| 10  | 450S-K06758(-0)                            | Spring Top plate         | 4        |     |                |                   |          |
| 11  | K06669(4)-G                                | Spring U-Bolt            | 8        |     |                |                   |          |
| 12  | 450S-K04595(B1)                            | Spring Shim              | 4        |     |                |                   |          |
| 13  | K06760(-1)                                 | Spring Axle Top Plate    | 4        |     |                |                   |          |
| 14  | K06761(-1)                                 | Spring Axle Bottom Plate | 4        |     |                |                   |          |
| 15  | HDZ13T341526010                            | Rear Axle                | 1        |     |                |                   |          |
| 16  | EC102CN-P23F76-G06-24DD<br>C02333080130140 | Hydraulic Lock Valve     | 2        |     |                |                   |          |
| 17  | 9735000000                                 | Quick Release Valve      | 3        |     |                |                   |          |
| 18  | 9730110010                                 | Relay Valve              | 1        |     |                |                   |          |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
DIMENSIONS ARE IN INCHES  
Dual dimensions are in mm  
Reference dimensions are in ( )

TOLERANCES:  
Fractional ± 1/8"  
Angular: MACH ± 0.5° BEND ± 2°  
Machined/Drilled Holes: ± 0.01

All Others  
x.x ± 0.10  
x.xx ± 0.06  
x.xxx ± 0.03

Part Description  
Axle Assembly

Part Number  
550S-0201000

Revision  
-0


DRAWN BY JND DATE 01/04/2020

SCALE: 3.2

WEIGHT:

SHEET 1 OF 1

| Num | Part Num.       | Description             | Quantity |
|-----|-----------------|-------------------------|----------|
| 1   | 550S-K05066     | Inner Catwalk           | 2        |
| 2   | 550S-K05067     | Outer Catwalk           | 2        |
| 3   | 550S-K07464(-0) | Outer Catwalk Support 1 | 1        |
| 4   | 550S-K05004     | Frame-Right             | 1        |
| 5   | 550S-K05003     | Frame-Left              | 1        |
| 6   | 450S-K04247(-0) | Pads Support            | 6        |
| 7   | 550S-K07468(-0) | Outer Catwalk Support 2 | 1        |
| 8   | 550S-K05114(A0) | Support Arm 2           | 4        |
| 9   | 550S-K04380(B0) | Stair Assembly          | 2        |
| 10  | 450S-K05068(-0) | Stair Support           | 2        |
| 11  | 550S-K05114(A0) | Mounting Angle          | 1        |
| 12  | 550S-K05065     | Mud Flap                | 6        |
| 13  | 550S-K07469(-0) | Inner Catwalk Support 1 | 1        |
| 14  | 550S-K05112(A0) | Support Arm 1           | 3        |
| 15  | 550S-K07470(-0) | Inner Catwalk Support 2 | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|           |  |
|-----------|--|
| DATE:     |  |
| ASSEMBLY: |  |



UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|   |                    |                       |
|---|--------------------|-----------------------|
| Part Description<br><b>Catwalk Assembly</b> |                    | Revision<br><b>-0</b> |
| Part Number<br><b>550S-0102000</b>          |                    |                       |
| DRAWN BY<br>JND                             | DATE<br>01/04/2020 | SCALE: 3:2            |
| WEIGHT:                                     |                    | SHEET 1 OF 1          |

| Num | Part Num.    | Description     | Quantity |
|-----|--------------|-----------------|----------|
| 1   | 550S-0301126 | Front Roof      | 1        |
| 2   | 550S-0301127 | Middle Roof     | 1        |
| 3   | 550S-0301128 | Rear Roof       | 1        |
| 4   | 550S-0301132 | Rear Plate      | 1        |
| 5   | 550S-0301135 | Side Panel I    | 1        |
| 6   | 550S-0301120 | Left Door       | 1        |
| 7   | 550S-0301134 | Electrical Door | 1        |
| 8   | 550S-0301133 | Side Panel II   | 1        |
| 9   | 550S-0301100 | Doghouse Frame  | 1        |
| 10  | 550S-0301131 | Front Plate     | 1        |
| 11  | 550S-0301136 | Side Panel III  | 1        |
| 12  | 550S-0301120 | Right Door      | 1        |
| 13  | 550S-0301137 | Side Panel IV   | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|           |                      |
|-----------|----------------------|
| DATE:     | DRAWING NOT TO SCALE |
| ASSEMBLY: |                      |


UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ± 0.5° BEND ± 2°  
 Machined/Drilled Holes: ± 0.01

All Others  
 x.x ± 0.10  
 x.xx ± 0.06  
 x.xxx ± 0.03

|                                       |                    |                |        |
|---------------------------------------|--------------------|----------------|--------|
| Part Description<br>Doghouse Assembly |                    | Revision<br>-0 |        |
| Part Number<br>550S-0301000           |                    |                |        |
| DRAWN BY<br>JND                       | DATE<br>01/04/2020 | SCALE<br>3:2   | WEIGHT |
|                                       |                    | SHEET 1 OF 1   |        |

| Num | Part Num.        | Description      | Quantity |
|-----|------------------|------------------|----------|
| 1   | 550S-0301100     | Doghouse         | 1        |
| 2   | 550S-0102000     | Catwalk Assembly | 1        |
| 3   | GS-LCL1101A-001  | Light            | 6        |
| 4   | 550S-1502015     | Bracket I        | 20       |
| 5   | 550S-1502012     | Rail II          | 2        |
| 6   | 550S-1502011     | Rail I           | 6        |
| 7   | 550S-1502014     | Bracket II       | 2        |
| 8   | 75920            | On-Off Switch    | 1        |
| 9   | MG-F002SS        | Door Support     | 2        |
| 10  | 550S-1502013     | Rail III         | 2        |
| 11  | MS857            | Lock             | 2        |
| 12  | CF-218           | 220V-Power       | 2        |
| 13  | LTL1073RF        | Brake Lamp       | 2        |
| 14  | GS-LTL1073RF-001 | Turning Lamp     | 2        |
| 15  | LTL3600R         | Strip Lamp       | 1        |
| 16  | GS-LWL1300-002   | Beacon Lamp      | 2        |
| 17  | SM6054           | Reversing Lamp   | 2        |
| 18  | 380              | Buzzer           | 2        |
| 19  | SM9101B123       | Doghouse Lamp    | 2        |
| 20  | CE4T-10R-11      | Emergency switch | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.


|          |                      |
|----------|----------------------|
| MATERIAL | DRAWING NOT TO SCALE |
| ASSEMBLY |                      |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|   |                    |                |        |
|---|--------------------|----------------|--------|
| Part Description<br>Doghouse Component Assembly |                    | Revision<br>-0 |        |
| Part Number<br>550S-0311000-1                   |                    |                |        |
| DRAWN BY<br>JND                                 | DATE<br>01/04/2020 | SCALE<br>3:2   | WEIGHT |
|   |                    | SHEET 1 OF 1   |        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |                      |
|----------|----------------------|
| MATERIAL | DRAWING NOT TO SCALE |
| ASSEMBLY |                      |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01


All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|  |                                 |
|--|---------------------------------|
| Part Description<br><b>Doghouse Component Assembly</b> | Revision<br><b>-0</b>           |
| Part Number<br><b>550S-0311000-2</b>                   |                                 |
| DRAWN BY: JND DATE: 01/04/2020                         | SCALE: 3:2 WEIGHT: SHEET 1 OF 1 |

| Num | Part Num.          | Description     | Quantity |
|-----|--------------------|-----------------|----------|
| 1   | CBHB-F550-AF15     | Fan Drive Pump  | 1        |
| 2   | CMF-E550S-AFPS     | Fan Drive Motor | 1        |
| 3   | KP30.31S0          | Steering Pump   | 1        |
| 4   | PV_JR_L_S45B_PC_21 | Work Pump       | 1        |
| 5   | HPV02-105L-E1D2    | Drive Pump      | 1        |
| 6   | HMV105-E6          | Linde motor     | 1        |

### Working pressures

- 1. 0-200 bar
- 3. 0-120 bar
- 4. 0-140 bar
- 5. 0-420 bar



KODIAK


PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |                      |
|----------|----------------------|
| MATERIAL | DRAWING NOT TO SCALE |
| ASSEMBLY |                      |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )  
 TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ± 0.5° BEND  
 Machined/Drilled Holes:  
 All Others  
 xx ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|                                |                    |                |        |
|--------------------------------|--------------------|----------------|--------|
| Part Description<br>Pump-Motor |                    | Revision<br>-0 |        |
| Part Number<br>550S-0500000-3  |                    |                |        |
| DRAWN BY<br>JND                | DATE<br>01/04/2020 | SCALE<br>3,2   | WEIGHT |
|                                |                    | SHEET 1 OF 1   |        |

| Num | Part Num.          | Description                 | Quantity | 39 | D25-1500               | Compressor Inlet Hose   | 1 |
|-----|--------------------|-----------------------------|----------|----|------------------------|-------------------------|---|
| 1   | KA70-9             | Prefilter                   | 1        | 40 | KDYK-CS-G05            | Coolant Pipe 2          | 1 |
| 2   | 216-224            | T-Hoop I                    | 1        | 41 | KDYK-CS-G04            | Coolant Pipe 1          | 1 |
| 3   | Y060119            | Silicone Hose I             | 1        | 42 | 550S-121533            | Holder                  | 1 |
| 4   | KDYK-IS-G01        | Pipe Weldment I             | 1        | 43 | 550S-101531            | Pipe Holder             | 1 |
| 5   | AH8822             | Air Filter                  | 1        | 44 | D25-120                | Coolant Compensate Pipe | 1 |
| 6   | 3630688 (Y0600055) | Silicone Hose II            | 1        | 45 | D10-800                | Silicone Hose           | 1 |
| 7   | 186-194            | T-Hoop VII                  | 1        | 46 | D10-2500               | Silicone Hose           | 1 |
| 8   | 148-156            | T-Hoop III                  | 2        | 47 | WG9725230042GKC105     | Air Cylinder            | 1 |
| 9   | Y050621            | Air Filter Mount            | 1        | 48 | 550S-K055800           | Brake Holder            | 1 |
| 10  | 550S-0500050       | Right Isolator              | 1        | 49 | QDF-2                  | Brake                   | 1 |
| 11  | 12JSD240TA         | Transmission                | 1        | 50 | 550S-K055798           | Flange                  | 1 |
| 12  | 550S-K05577        | Transmission Mount Weldment | 1        | 51 | 550S-K055788-1         | Brake Disk              | 1 |
| 13  | QSZ13-2020-14_ASM  | Engine                      | 1        | 52 | 10JSX220A-1708090-1    | Transmission Cooler     | 1 |
| 14  | 550S-0500050       | Left Isolator               | 1        | 53 | CBHB-F550-AF15         | Fan Drive Pump          | 1 |
| 15  | Y070917            | Stainless Steel Pipe I      | 1        | 54 | CMF-E550S-AFPS         | Fan Drive Motor         | 1 |
| 16  | 137-145            | T-Hoop IV                   | 1        | 55 | 02980900Z              | Fuse                    | 2 |
| 17  | Y060001            | Silicone Hose III           | 1        | 56 | 391630221AP33121062800 | Relay                   | 1 |
| 18  | CR450S-0599213     | Hoop 107-115                | 6        | 57 | QDF-2 Brake Pad        | Brake Pad               | 2 |
| 19  | Y3071049(L190)     | Silicone Hose $\phi$ 102    | 3        | 58 | FEC170001-36           | Clutch Assembly         | 1 |
| 20  | 186917             | V-Hoop V                    | 1        | 59 | FEC1283022             | Clutch Plate            | 1 |
| 21  | KDYK-ES-G01        | Pipe Weldment II            | 1        | 60 | 125693                 | Clutch Release Bearing  | 1 |
| 22  | 550S-PAIQ001       | Exhaust Pipe                | 1        | 61 | 95-103                 | Hoop 95-103             | 2 |
| 23  | 550S-0104150       | Engine Front Mount          | 1        |    |                        |                         |   |
| 24  | 550S-1300510       | Radiator Mount              | 1        |    |                        |                         |   |
| 25  | Y000084            | Radiator                    | 1        |    |                        |                         |   |
| 26  | KDYK-CS-G01        | Stainless Steel Pipe II     | 1        |    |                        |                         |   |
| 27  | KDYK-CS-G02        | Stainless Steel Pipe III    | 1        |    |                        |                         |   |
| 28  | Y050005-1          | Hoop                        | 2        |    |                        |                         |   |
| 29  | LD20121220-03      | Muffler                     | 1        |    |                        |                         |   |
| 30  | Y060014-K(L=160)   | Silicone Hose $\phi$ 63     | 4        |    |                        |                         |   |
| 31  | 67-75              | Hoop 67-75                  | 10       |    |                        |                         |   |
| 32  | KDYK-CS-G03        | Stainless Steel Pipe IV     | 1        |    |                        |                         |   |
| 33  | Y060056(H=150)     | 90° Silicone Hose           | 1        |    |                        |                         |   |
| 34  | CR450S-0599125     | Plate                       | 2        |    |                        |                         |   |
| 35  | CR450S-0599252     | T-Hoop 60                   | 2        |    |                        |                         |   |
| 36  | CR450S-0599212     | Silicone Hose 90            | 1        |    |                        |                         |   |
| 37  | CR450S-0599124     | T-Hoop 106                  | 2        |    |                        |                         |   |
| 38  | 550S-101532        | Airpipe Holder              | 1        |    |                        |                         |   |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |
|----------|
| MATERIAL |
| ASSEMBLY |

UNLESS OTHERWISE SPECIFIED:  
DIMENSIONS ARE IN INCHES  
Dual dimensions are in mm  
Reference dimensions are in ( )

TOLERANCES:  
Fractionals: 1/8"  
Angular: MACH 0.5° BEND  
Machined/Drilled Holes:

All Others  
x.x ±0.10  
x.xx ±0.06  
x.xxx ±0.03

Part Description  
Power System Assembly

Part Number  
550S-0500000-1A

Revision


-1

DRAWN BY JND DATE 02/29/2024

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1



DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractionals: 1/8"  
 Angular: MACH 0.5° BEND  
 Machined/Drilled Holes:

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03



|                       |      |              |            |
|-----------------------|------|--------------|------------|
| Part Description      |      | Revision     |            |
| Power System Assembly |      | -1           |            |
| Part Number           |      | Revision     |            |
| 550S-0500000-2A       |      |              |            |
| DRAWN BY              | JND  | DATE         | 02/29/2024 |
| SCALE:                | 3, 2 | WEIGHT:      |            |
|                       |      | SHEET 1 OF 1 |            |

KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

| Num | Part Num.        | Description                      | Quantity |
|-----|------------------|----------------------------------|----------|
| 1   | 550S-K04832-1    | Transmmision Mounting Side Plate | 2        |
| 2   | Q150B22130T      | Bolt M22*130                     | 4        |
| 3   | 22004-3          | Isolator                         | 4        |
| 4   | 550S-K08589(-0)  | Washer                           | 2        |
| 5   | 550S-K05584(-0)  | Plate                            | 4        |
| 6   | DTF6175PTM22*2.5 | Nut                              | 4        |
| 7   | 367-97-121       | Transfer Case                    | 1        |
| 8   | HMV105-E6        | Linde motor                      | 1        |
| 9   | 550S-K07225      | Transmmision Mounting Weldment   | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|           |                      |
|-----------|----------------------|
| DATE:     | DRAWING NOT TO SCALE |
| ASSEMBLY: |                      |


UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|                       |            |          |        |
|-----------------------|------------|----------|--------|
| Part Description      |            | Revision |        |
| Transmission Assembly |            | -0       |        |
| Part Number           |            | Revision |        |
| 550S-1002000          |            | -0       |        |
| DRAWN BY              | DATE       | SCALE    | WEIGHT |
| JND                   | 01/04/2020 | 3:2      |        |
| SHEET 1 OF 1          |            |          |        |

| Num | Part Num.         | Description               | Quantity |
|-----|-------------------|---------------------------|----------|
| 1   | QSZ13-C550        | Engine                    | 1        |
| 2   | C2874497          | Water                     | 1        |
| 3   | ∅16               | Tube                      | 1        |
| 4   | C4952629          | Thermostat                | 1        |
| 5   | ∅63.5             | Tube                      | 1        |
| 6   | Y000084           | Radiator                  | 1        |
| 7   | ∅63.5             | Tube                      | 1        |
| 8   | 4974917           | Pump                      | 1        |
| 9   | C2874497          | Water-Return              | 1        |
| 10  | ∅16               | Tube                      | 1        |
| 11  | YJH-Q15A.24V      | Heater                    | 1        |
| 12  | ∅16               | Tube                      | 1        |
| 13  | ∅16               | Tube                      | 1        |
| 14  | TY46G15AB-ZGZQ-09 | Cab heater/heat exchanger | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

MATERIAL  
 ASSEMBLY

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:

All Others  
 xx ±0.10  
 xxx ±0.06  
 0.03

Part Description

Engine Pre-heating

Part Number

CR550S-HEATER+RADIATOR

Revision

-0



DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1

| Num | Part Num.       | Description                     | Quantity |
|-----|-----------------|---------------------------------|----------|
| 1   | 270AB           | Fuel Tank Top washing Flange    | 1        |
| 2   | 550S-0405000    | Fuel Tank Body                  | 1        |
| 3   | GB/T 41-2000    | Nut                             | 1        |
| 4   | KB2128          | Fill Spout                      | 2        |
| 5   | KB4004          | Fuel Tank Filter                | 2        |
| 6   | PC200           | Fuel Tank Cover                 | 2        |
| 7   | TN-500JKM05123  | Level Sensor                    | 1        |
| 8   | 220AB           | Fuel Tank Bottom washing Flange | 1        |
| 9   | 550S-0405131    | Sensor Mounting Flange          | 1        |
| 10  | M22*1.5-M16*1.5 | Connector                       | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

Part Description

Fuel Tank Assembly

Part Number

550S-0405100

Revision

-0



DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:

SHEET 1 OF 1

| Num | Part Num.        | Description                | Quantity |
|-----|------------------|----------------------------|----------|
| 1   | 3201-2020.10     | Hydraulic Tank             | 1        |
| 2   | Q1851280TF30     | Bolt                       | 6        |
| 3   | EH50             | Isolator                   | 6        |
| 4   | 550S-1087719     | Washer                     | 6        |
| 5   | Q33012T13F3-P125 | Bolt                       | 6        |
| 6   | 550S-0800610     | Hydraulic Tank Right Mount | 1        |
| 7   | 550S-0800620     | Hydraulic Tank Left Mount  | 1        |
| 8   | QUQ2,5-40*2,0    | Air Filter                 | 1        |
| 9   | 550S-0800621     | Cover                      | 1        |
| 10  | RFA-400*20F-C    | Hydraulic Oil Filter       | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|           |                      |
|-----------|----------------------|
| DATE:     | DRAWING NOT TO SCALE |
| MATERIAL: |                      |
| ASSEMBLY: |                      |



UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|   |                    |                |        |
|---|--------------------|----------------|--------|
| Part Description<br>Hydraulic Tank Assembly |                    | Revision<br>-0 |        |
| Part Number<br>550S-0800630                 |                    |                |        |
| DRAWN BY<br>JND                             | DATE<br>01/04/2020 | SCALE<br>3:2   | WEIGHT |
|   |                    | SHEET 1 OF 1   |        |

| Num | Part Num.         | Description               | Quantity |
|-----|-------------------|---------------------------|----------|
| 1   | LTL1655A          | Side-Lamp                 | 4        |
| 2   | LTL1300           | Circular Strobe           | 2        |
| 3   | BC-XK013          | Beacon                    | 2        |
| 4   | HY-0169           | Rosco Side Mirror         | 1        |
| 5   | LML0470           | Lamp                      | 2        |
| 6   | JH20              | High&Low Beam Lamp        | 2        |
| 7   | 136.2265.GA.04    | Wiper Blade               | 3        |
| 8   | 127.3204.GA.D4    | Wiper Arm                 | 3        |
| 9   | RST-KODIAK001     | Right Glass               | 1        |
| 10  | LTL1657A          | Turning Light             | 2        |
| 11  | RST-KODIAK004     | Front Glass               | 1        |
| 12  | TY46G15AB-ZGZQ-09 | Cab heater/heat exchanger | 1        |
| 13  | RST-KODIAK002     | Left Glass                | 1        |
| 14  | 550S-1002015      | Handrail                  | 2        |
| 15  | K01649            | Cab                       | 1        |
| 16  | 141543730D4       | Wiper Motor               | 1        |
| 17  | 14154363014       | Wiper Motor               | 1        |
| 18  | 14154373014       | Wiper Motor               | 1        |
| 19  | 4613170230        | Brake Pedal               | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

MATERIAL \_\_\_\_\_  
 ASSEMBLY \_\_\_\_\_

DRAWING NOT TO SCALE

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:

All Others  
 .xx ±0.10  
 .xxx ±0.06  
 0.03

Part Description  
**Cab Assembly**

Part Number  
**K01649**

DRAWN BY JND DATE 01/04/2020



SCALE: 3:2

WEIGHT:

-0

SHEET 1 OF 1

| Num | Part Num.     | Description           | Quantity |
|-----|---------------|-----------------------|----------|
| 1   | RST-KODIAK006 | Left door view glass  | 1        |
| 2   | RST-KODIAK002 | Left side glass       | 1        |
| 3   | RST-KODIAK004 | Front glass           | 1        |
| 4   | RST-KODIAK001 | Right side glass      | 1        |
| 5   | RST-KODIAK005 | Right door view glass | 1        |
| 6   | RST-KODIAK003 | Rear glass            | 1        |
| 7   | RST-KODIAK008 | Left window glass     | 1        |
| 8   | RST-KODIAK007 | Right window glass    | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:

All Others:  
 xx ±0.10  
 xxx ±0.06  
 0.03

Part Description  
 Cab Glass Assembly

Part Number  
 K01649-01

DRAWN BY JND DATE 01/04/2020


SCALE: 3:2

WEIGHT:

-0

SHEET 1 OF 1

| Num | Part Num. | Description                             | Quantity | Note |
|-----|-----------|---|----------|------|
| 1   | 351571    | Dual analog accelerator position sensor | 2        |      |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |
|----------|
| MATERIAL |
| ASSEMBLY |


UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH ± 0.5° BEND ± 2°  
 Machined/Drilled Holes: ± 0.01

All Others  
 x.x ± 0.10  
 x.xx ± 0.06  
 x.xxx ± 0.03

|  |                    |                |        |
|--|--------------------|----------------|--------|
| Part Description<br>CR580S Location of all sensors |                    | Revision<br>-0 |        |
| Part Number<br>580S0902001                         |                    |                |        |
| DRAWN BY<br>JND                                    | DATE<br>01/04/2020 | SCALE<br>3:2   | WEIGHT |
|  |                    | SHEET 1 OF 1   |        |

| Num | Part Num.    | Description                         | Quantity |
|-----|--------------|-------------------------------------|----------|
| 1   | 0009830643   | Drive pump filter element           | 1        |
| 2   | 4324102412   | Air dryer                           | 1        |
| 3   | FF5687       | Secondary fuel filtration           | 1        |
| 4   | FS36260      | Primary fuel filter                 | 1        |
| 5   | FS36230      | Fuel/Water Separator                | 1        |
| 6   | FAX-400X20   | Hydraulic oil return filter element | 1        |
| 7   | AF26434      | Secondary air filter element        | 1        |
| 8   | AA2960       | Primary air filter element          | 1        |
| 9   | LF9080       | Engine oil filter element           | 1        |
| 10  | PBE0160F010N | Hydraulic oil filter                | 1        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

DRAWING NOT TO SCALE

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractions: 1/8"  
 Angular: MACH ±0.5° BEND  
 Machined/Drilled Holes:

All Others  
 .xx ±0.10  
 .xxx ±0.06  
 .003

Part Description  
**Engine filter element**

Part Number  
**CR550S-filter element -1**

Revision  
**-0**

DRAWN BY JND DATE 01/04/2020


SCALE: 3:2

WEIGHT:

SHEET 1 OF 1

|    |  |  |  |  |
|----|--|--|--|--|
| 12 |  |  |  |  |
|----|--|--|--|--|

| Num | Part Num.       | Description                          | Quantity | Note |
|-----|-----------------|--------------------------------------|----------|------|
| 1   | MBST3560        | Hydraulic oil temp                   | 1        |      |
| 2   | JKM05123        | Fuel level sensor                    | 1        |      |
| 3   | 090Q2665        | Drive pump pressure sensor           | 1        |      |
| 4   | 41V10H22        | Oil circulation pump pressure switch | 1        |      |
| 5   | MBS1250         | Oil circulation pump sensor          | 1        |      |
| 6   | 090Q2138        | Air pressure sensor                  | 1        |      |
| 7   | R1              | Gearbox speed sensor                 | 1        |      |
| 8   | Vert-X 32E7d836 | Front axle position sensor           | 1        |      |
| 9   | Vert-X 32E7d836 | Rear axle position sensor            | 1        |      |
| 10  | 2872769         | Engine coolant level sensor          | 1        |      |
| 11  | 5300516         | Water in fuel sensor                 | 1        |      |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |  |
|----------|--|
| MATERIAL |  |
| ASSEMBLY |  |




UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional: 1/8"  
 Angular: MACH±0.5° BEND±2°  
 Machined/Drilled Holes: ±0.01

All Others  
 x.x ±0.10  
 x.xx ±0.06  
 x.xxx ±0.03

|                  |                                |        |              |
|------------------|--------------------------------|--------|--------------|
| Part Description | CR580S Location of all sensors |        |              |
| Part Number      | 580S0902000                    |        |              |
| Revision         | -0                             |        |              |
| DRAWN BY         | JND                            | DATE   | 01/04/2020   |
| SCALE            | 3:2                            | WEIGHT |              |
|                  |                                |        | SHEET 1 OF 1 |

| Num | Part Num.          | Description          | Quantity |
|-----|--------------------|----------------------|----------|
| 1   | Q150B1645TF3       | M16 × 2 × 45 Bolt    | 20       |
| 2   | Q334B16            | M16 × 2 Lock Nut     | 20       |
| 3   | NJ130-730          | Driveline            | 1        |
| 4   | NJ130-705          | Driveline            | 1        |
| 5   | Q18501035TF3-P150  | M10 × 1.5 × 35 Bolt  | 16       |
| 6   | Q32310             | M10 × 1.5 Lock Nut   | 16       |
| 7   | Q18501470TF30-P150 | M14 × 1.5 × 70 Bolt  | 4        |
| 8   | Q334B14            | M14 × 1.5 Nut        | 14       |
| 9   | 395-1820           | Driveline            | 1        |
| 10  | Q18501645TF3       | M16 × 1.5 × 55 Bolt  | 8        |
| 11  | Q32316             | M16 × 1.5 Lock Nut   | 8        |
| 12  | K00002             | Shear Pin            | 6        |
| 13  | Q32312             | M12 × 1.75 Nut       | 6        |
| 14  | Q40312             | ∅12 Spring Washer    | 10       |
| 15  | Q151B1640TF3       | M16 × 1.5 × 40 Bolt  | 10       |
| 16  | 0082-650           | Driveline            | 1        |
| 17  | Q150B1235TF3       | M12 × 1.75 × 35 Bolt | 4        |
| 18  | 113200246          | Driveline            | 1        |
| 19  | Q151B1435TF3-P150  | M14 × 1.5 × 35 Bolt  | 4        |
| 20  | Q40314             | ∅14 Spring Washer    | 4        |
| 21  | ∅28 × 15 × 4       | ∅28 Washer           | 4        |
| 22  | ∅35 × 106          | U.J Cross Assy       | 4        |
| 23  | ∅57 × 152          | U.J Cross Assy       | 2        |
| 24  | ∅57 × 144          | U.J Cross Assy       | 2        |
| 25  | NJ131              | U.J Cross Assy       | 2        |



KODIAK

PROPRIETARY AND CONFIDENTIAL  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KODIAK AMERICA.  
 REPRODUCTION OR DISTRIBUTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION OF  
 KODIAK AMERICA IS PROHIBITED.

|          |                      |
|----------|----------------------|
| MATERIAL | DRAWING NOT TO SCALE |
| ASSEMBLY |                      |

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 Dual dimensions are in mm  
 Reference dimensions are in ( )

TOLERANCES:  
 Fractional ± 1/8"  
 Angular: MACH ± 0.5° BEND  
 Machined/Drilled Holes:

All Others  
 x.xx ±0.10  
 x.xxx ±0.06  
 0.03

Part Description

Driveline Assembly

Part Number

550S-0600000

Revision



-0

DRAWN BY JND DATE 01/04/2020

SCALE: 3:2

WEIGHT:




SHEET 1 OF 1






|       |      |        |        |       |           |          |          |      |
|-------|------|--------|--------|-------|-----------|----------|----------|------|
|       |      |        |        |       | Driveline |          | 0082-650 |      |
| DES.  | CHK. | CHANGE | TECHN. | SIGN. | DATE      | APP.     | ALLOW.   | DATE |
| CONV. |      |        |        |       |           |          |          |      |
|       |      |        |        |       |           | SHEET OF |          |      |






113200246



Part number: 113200246



|        |      |        |        |      |           |        |           |  |
|--------|------|--------|--------|------|-----------|--------|-----------|--|
|        |      |        |        |      | Driveline |        | NJ130-705 |  |
| MARK   | ADD. | CHANGE | SIGN.  | DATE | EDITION   | WEIGHT | SCALE     |  |
| DES.   |      |        | TECHN. |      |           | KG     | 1:1       |  |
| APP.   |      |        | ALLOW. |      |           |        |           |  |
| CONVT. |      |        | DATE   |      | SHEET/OF  |        |           |  |



|       |      |        |        |      |           |      |           |  |
|-------|------|--------|--------|------|-----------|------|-----------|--|
|       |      |        |        |      | Driveline |      | NJ130-730 |  |
| MARK  | ADD. | CHANGE | SIGN.  | DATE | EDITION   | FIG. | SCALE     |  |
| DES.  |      |        | TECHN. |      |           |      |           |  |
| APP.  |      |        | ALLOW. |      |           |      |           |  |
| CONV. |      |        | DATE   |      | SHEET/OF  |      |           |  |

## **Section 2. List of recommended tools**

### **Allen Drivers**

1. Metric Allen wrench set 2-millimeter to 17-millimeter

### **Socket Drivers**

1. Metric (shallow and deep) 5-millimeter to 27-millimeter
2. Short, medium, long extensions
3. Ratchet handle
4. Universal joint
5. Torque wrench
6. Breaker bar

### **Feeler Gauge Set**

1. Set A for exhaust
2. Set B handle for Intake

### **Electrical tools**

1. Multi-meter
  - a. Auto ranging
  - b. Digital readout
2. Crimping tool
3. Wire stripping tool
4. Wire cutters
5. Handheld torch or flashlight

### **Pliers**

1. Adjustable
2. Needle nose
3. Vise-grip set
4. Adjustable joint
5. Locking
6. Side cutters
7. Slip-joint
8. Snap ring
  - a. Small reversible
  - b. Large reversible
  - c. Flat with 40mm minimum opening
9. Brake spring
10. Battery nut

### **Pry Bar Set**

1. 30cm
2. 60cm

3. 90cm

### **Screw Drivers**

1. Philips
  - a. Short, medium, long
2. Flathead
  - a. Short, medium, long
3. #1 to #3

### **Wrenches**

1. Metric, 8-millimeter to 22-millimeter
2. Adjustable wrench
  - a. Small, medium, large
3. Filter wrench

## **Section 3. Warranty Procedure**

For Kodiak to provide warranty parts, 8 items must be submitted to determine if the equipment failure was due to improper maintenance, operator error or warranty. The following must be submitted with each request.

1. Serial number of the machine
2. Location of the machine
3. Hours on the machine (can be obtained on the monitor)
4. Nature of the failure
5. Pictures of the failure
6. Contact person to discuss what happened
7. Name of the individual operation the machine
8. Name of person who maintained or inspected the machine prior to operation